

Configuring MAC Authentication in the HP ProCurve Wireless Access Point 420

MAC Authentication Mode	MAC Authentication	Local MAC Authentication	MAC Authentication Settings			RADIUS	Comments
		System Default	MAC Address	Permission			
				Deny	Allow		
Local MAC authentication	Local MAC	Deny	xx-xx-xx-xx-xx-xx		*	Not needed	All MAC addresses <u>denied unless permission specifically allowed</u> in MAC Authentication Table. Can be combined with other methods for improved security.
Local MAC authentication	Local MAC	Allow	xx-xx-xx-xx-xx-xx	*		Not needed	All MAC addresses <u>allowed unless permission specifically denied</u> in the MAC Authentication Table. Can be combined with other methods for improved security.
Remote MAC authentication	Radius MAC	MAC address permission policy based on RADIUS server configuration.	RADIUS Server Use PAP authentication and 12 contiguous characters for the MAC address i.e. 0030f18c83b4. User and password on the RADIUS server must be the same.			MUST	Works with authentication Open/Shared AND encryption Disabled/WEP Static.