



HP ProBook 4445s Notebook PC
HP ProBook 4446s Notebook PC

Maintenance and Service Guide

© Copyright 2012 Hewlett-Packard
Development Company, L.P.

Bluetooth is a trademark owned by its proprietor and used by Hewlett-Packard Company under license. Advanced Micro Devices, Inc. AMD are trademarks of Advanced Micro Devices, Inc. Microsoft and Windows are either trademarks or registered trademarks of Microsoft Corporation in the United States and/or other countries. SD Logo is a trademark of its proprietor.

The information contained herein is subject to change without notice. The only warranties for HP products and services are set forth in the express warranty statements accompanying such products and services. Nothing herein should be construed as constituting an additional warranty. HP shall not be liable for technical or editorial errors or omissions contained herein.

First Edition: October 2012

Document Part Number: 702228-001

Safety warning notice

 **WARNING!** To reduce the possibility of heat-related injuries or of overheating the computer, do not place the computer directly on your lap or obstruct the computer air vents. Use the computer only on a hard, flat surface. Do not allow another hard surface, such as an adjoining optional printer, or a soft surface, such as pillows or rugs or clothing, to block airflow. Also, do not allow the AC adapter to contact the skin or a soft surface, such as pillows or rugs or clothing, during operation. The computer and the AC adapter comply with the user-accessible surface temperature limits defined by the International Standard for Safety of Information Technology Equipment (IEC 60950).

Table of contents

1 Product description	1
2 External Component Identification	7
Top	7
TouchPad	7
Lights	8
Buttons, speakers, and fingerprint reader (select models only)	9
Keys - Windows models	11
Keys - SUSE Linux models	12
Front	13
Right	14
Left	14
Display	15
Bottom	17
Identifying the bottom parts of the computer	18
3 Illustrated parts catalog	20
Service tag	20
PCID Label	21
Computer major components	22
Display components	25
Plastics Kit	25
Cable Kit	27
Mass storage devices	28
Miscellaneous parts	28
Sequential part number listing	29
4 Removal and replacement procedures	32
Preliminary replacement requirements	32
Tools required	32
Service considerations	32
Plastic parts	32
Cables and connectors	33
Drive handling	33
Grounding guidelines	34
Electrostatic discharge damage	34

Packaging and transporting guidelines	35
Workstation guidelines	35
Equipment guidelines	36
Component replacement procedures	37
Service tag	37
Battery	38
Bottom door	39
Optical drive	40
Hard drive	43
Memory modules	45
WLAN/Bluetooth combo card	47
Keyboard	49
Metal heat shield	51
Fan	52
Top cover	53
Audio board	59
Fingerprint reader	61
Power button/function button	62
USB Module	63
Speaker	65
System board	66
Heat sink	69
Processor	72
RTC battery	74
Power cable	76
Display assembly	77
5 Computer Setup (BIOS) and Advanced System Diagnostics	84
Windows 7 – Computer Setup (BIOS) and Advanced System Diagnostics	84
Using Computer Setup	84
Starting Computer Setup	84
Navigating and selecting in Computer Setup	84
Restoring factory settings in Computer Setup	85
Updating the BIOS	85
Downloading SoftPaqs to update the BIOS	85
BIOS management using system diagnostics	86
Using f10 setup to update the BIOS	86
Determining the BIOS version	86
Downloading a BIOS update	87
BIOS Setup Menu	88
Main menu	88

Security menu	88
Diagnostics menu	88
Using Advanced System Diagnostics	88
Windows 8 – Computer Setup (BIOS) and Advanced System Diagnostics	90
Using Computer Setup	90
Starting Computer Setup	90
Navigating and selecting in Computer Setup	90
Restoring factory settings in Computer Setup	91
Updating the BIOS	91
Determining the BIOS version	91
Downloading a BIOS update	92
Using Advanced System Diagnostics	93
SUSE Linux – Computer Setup (BIOS) and Advanced System Diagnostics	94
Starting Computer Setup	94
Using Computer Setup	94
Navigating and selecting in Computer Setup	94
Restoring factory settings in Computer Setup	95
Updating the BIOS	95
Determining the BIOS version	95
Downloading a BIOS update	96
Using Advanced System Diagnostics	97
6 Specifications	98
Computer specifications	98
35.6-cm (14.0-in), HD display specifications	99
Hard drive specifications	99
Blu-ray BD-R/RE DVD±RW SuperMulti DL Drive	100
DVD-ROM Drive specifications	101
Specification information in Device Manager	101
7 Backup and recovery	103
Windows 7 - Backup and recovery	103
Creating recovery media with HP Recovery Disc Creator	104
Creating recovery media	104
Backing up your information	104
Performing a system recovery	105
Using the Windows recovery tools	105
Using f11 recovery tools	106
Using a Windows 7 operating system DVD (purchased separately)	107
Windows 8 - Backup and recovery	108
Backing up your information	108

Performing a system recovery	109
Using the Windows recovery tools	109
Using f11 recovery tools	109
Using Windows 8 operating system media (purchased separately)	110
Using Windows Refresh for quick and easy recovery	110
Remove everything and reinstall Windows	111
Using HP Software Setup	111
SUSE Linux - Backup and recovery	112
Creating backups	112
Backing up your information	112
Performing a system recovery	113
USB Recovery option (select models only)	113
Remove everything and reinstall SUSE Linux	114
8 Power cord set requirements	116
Requirements for all countries and regions	116
Requirements for specific countries and regions	116
9 Recycling	118
Battery	118
Display	118
Index	124

1 Product description

Category	Description	4445s (UMA)	4446s (disc)
Product Name	HP ProBook 4445s Notebook PC	√	
	HP ProBook 4446s Notebook PC		√
Processors (Accelerated Processing Unit [APU])	AMD A6-4400M, 3.2-GHz Max/2.7-GHz Base, 1-MB L2 cache, dual-core, 35W Graphics: HD 7520G	√	√
	AMD-A8 4500M, 2.8-GHz Max/1.9-GHz Base, 4-MB L2 cache, quad-core, 35W Graphics: HD 7640G	√	√
	AMD-A4-4300M, 3.0-GHz Max/2.5-GHz Base, 1-MB L2 cache, dual core, 35W Graphics: HD 7420G	√	√
Fusion Controller Hub (Chipset)	AMD A70M FCH	√	√
Graphics	AMD UMA Processor-specific, see Processors .	√	
	AMD Discrete Graphics: A4-4300M—Graphics branding HD7420G + AMD Radeon™ 7650M or A6-4400M — Graphics branding HD 7520G + AMD Radeon 7650M -or- A8-4500M — Graphics branding HD 7640G + AMD Radeon 7650M		√
Panel	All display assemblies include 2 wireless local area network (WLAN) antennas		
	35.6-cm (14.0-inch) HD, Anti-glare, 1366x768	√	
	35.6-cm (14.0-inch) HD, Anti-glare, 1366x768, with camera	√	√
	35.6-cm (14.0-inch) HD, BrightView, 1366x768	√	
	35.6-cm (14.0-inch) HD, BrightView, 1366x768, with camera	√	√
Memory	Two customer-accessible/upgradeable memory module slots supporting up to 8 GB of RAM	√	√
	Supports dual-channel memory	√	√
	PC-3-12800, 1600-MHz, DDR3	√	√

Category	Description	4445s (UMA)	4446s (disc)
	Supports the following configurations: <ul style="list-style-type: none"> • 8192 (4096 × 2) (dual channel) • 6144 (4096 + 2048) (dual channel) • 4096 (2048 × 2) (dual channel) • 4096 (4096 × 1) • 2048 (2048 × 1) 	√	√
Hard drives	Supports 7-mm, 9.5-mm, 12.7-mm, and 6.35-cm (2.50-in) SATA hard drives with HP 3D DriveGuard	√	√
	Customer-accessible	√	√
	Supports the following drives: <ul style="list-style-type: none"> • 750-GB, 7200 rpm (2.5 in) • 750-GB, 5400 rpm (2.5 in) • 640-GB, 5400 rpm (2.5 in) • 500-GB, 7200 rpm (2.5 in) • 500-GB, 5400 rpm (2.5 in) • 320-GB, 7200 rpm (2.5 in) • 320-GB, 5400 rpm (2.5 in) 	√	√
Fixed optical drives	Supports the following 12.7-mm SATA optical drives: <ul style="list-style-type: none"> • DVD+/-RW DL SuperMulti DL • Blu-ray ROM DVD+/-RW SuperMulti DL 	√	√
	Supports no optical drive option	√	√
Audio/Visual	Integrated dual-array microphone (webcam models only)	√	√
	Integrated mono (non-webcam models)	√	√
	Stereo speakers (2)	√	√
	Integrated webcam (720p HD)	√	√
	Supports no camera option	√	
	Headphone and microphone jacks	√	√
Ethernet	Realtek RTL8151FH-CG 10/100/1000	√	√
	S3/S4/S5 wake on LAN	√	√
	Ethernet cable not included	√	√
Wireless	Integrated WLAN options by way of wireless module:		
	Two WLAN antennas built into display assembly	√	√
	Supports “no WLAN” option	√	√

Category	Description	4445s (UMA)	4446s (disc)
	Supports the following WLAN formats:	√	√
	<ul style="list-style-type: none"> • Ralink RT5390F 802.11 b/g/n 1x1 PCIe HMC • Ralink RT3290LE 802.11 b/g/n 1x1 WiFi and Bluetooth 4.0 Combo Adapter • Ralink RT5390R 802.11 b/g/n 1x1 WiFi Adapter • Atheros 9485GN 802.11 b/g/n 1x1 WiFi and 3012 Bluetooth 4.0 Combo Adapter • Atheros AR9485 802.11b/g/n WiFi Adapter • Atheros AR9462 802.11 a/b/g/n 2x2 BT4.0 combo • Atheros AR9565 802.11 b/g/n 1x1 WiFi + BT4.0 combo Adapter • Broadcom 4313GN 802.11b/g/n 1x1 WiFi and 20702 Bluetooth Combo Adapter 		
	Integrated personal area network (WPAN) options by way of Bluetooth® module:		
	Bluetooth 4.0 only supported by combo card	√	√
External media card	6-in-1 Digital Media Reader Slot. Supports: SD, SDHC, SDXC., MMC, MMC+. and Memory Stick	√	√
Ports	Audio-in (stereo microphone)	√	√
	Audio-out (stereo headphone)	√	√
	RJ-45 (Ethernet, includes link and activity lights)	√	√
	USB 3.0 (2)	√	√
	USB 2.0 (2)	√	√
	VGA (Dsub 15-pin) supporting 1600 × 1200 external resolution at 75-Hz (hot plug/unplug with auto-detect)	√	√
	HDMI	√	√
	Multi-pin AC port	√	√
Keyboard/pointing devices	Full-sized keyboard	√	√
	TouchPad includes: supports 2-way scroll with legend, taps enabled by default, 2-finger scrolling and zoom enabled by default	√	√
Power requirements	Smart AC adapter with localized cable plug support (3-wire plug with ground pin):	√	√
	90-W		√
	65-W	√	
	9-cell, 93-Wh Li-ion battery	√	√
	6-cell, 47-Wh Li-ion battery	√	√
Security	Integrated fingerprint reader	√	√
	Support Kensington security lock	√	√
	Support no fingerprint reader option	√	√

Category	Description	4445s (UMA)	4446s (disc)
Operating system	Preinstalled:		
	Windows 7 Professional 64 with Microsoft Basics	√	√
	Windows 7 Home Premium 64 with Microsoft Basics	√	√
	Windows 8 ML 64 with Microsoft Basics	√	√
	Windows 8 PRO 64 with Microsoft Basics	√	√
	Novell™: SuSE Linux™ – SLED 11 64 bit SP2	√	√
	FreeDOS	√	√
	Preinstalled with Microsoft Office:		
	Windows 7 Professional 64 with Microsoft Office 2010 Starter (excludes Japan)	√	√
	Windows 7 Professional 64 with Microsoft Office 2010 Starter, PPP (EDGI)	√	√
	Windows 7 Professional 64 with Microsoft Office 2010 Professional (Japan only)	√	√
	Windows 7 Professional 64 with Microsoft Office 2010 Personal (Japan only)	√	√
	Windows 7 Professional 64 with Microsoft Office 2010 Home and Business (Japan only)	√	√
	Windows 7 Home Premium with Microsoft Office 2010 Starter, PPP (EDGI)	√	√
	Windows 7 Home Premium 64 with Microsoft Office 2010 Home and Business (Japan only)	√	√
	Windows 7 Home Premium 64 with Microsoft Office 2010 Personal (Japan only)	√	√
	Windows 7 Home Premium 64 with Microsoft Office 2010 Starter (excludes Japan)	√	√
	Windows 7 Home Premium 64 with Microsoft Office Professional (Japan only)	√	√
	Windows 7 Home Basic 64 with Microsoft Office 2010 Starter (excludes Japan)	√	√
	Windows 7 Home Basic 64 with Microsoft Office 2010 Starter, PPP (EDGI)	√	√
	Windows 8 Pro 64 DPK with Windows 7 Pro 64 image with Office 2010 Starter (excludes Japan)	√	√
	Windows 8 Pro 64 DPK with Windows 7 Pro 64 image with Office 2010 Personal (Japan only)	√	√
	Windows 8 Pro 64 DPK with Windows 7 Pro 64 image with Office 2010 Home and Business (Japan only)	√	√
	Windows 8 Pro 64 DPK with Windows 7 Pro 64 image with Office 2010 Professional (Japan only)	√	√


Category	Description	4445s (UMA)	4446s (disc)
	Windows 8 ML 64 with Microsoft Office 2010 Transition OPK (excludes Japan)	√	√
	Windows 8 EM 64 with Microsoft Office 2010 Transition OPK (excludes Japan)	√	√
	Windows 8 CH 64 with Microsoft Office 2010 Transition OPK (Peoples Republic of China only)	√	√
	Windows 8 ML 64 with Microsoft Office 2010 Personal (Japan only)	√	√
	Windows 8 ML 64 with Microsoft Office 2010 Home & Business (Japan only)	√	√
	Windows 8 ML 64 with Microsoft Office 2010 Professional (Japan only)	√	√
	Windows 8 Pro 64 with Microsoft Office 2010 Transition OPK (excludes Japan)	√	√
	Windows 8 Pro 64 with Microsoft Office 2010 Personal (Japan only)	√	√
	Windows 8 Pro 64 with Microsoft Office 2010 Home & Business (Japan only)	√	√
	Windows 8 Pro 64 with Microsoft Office 2010 Professional (Japan only)	√	√
	Restore Media:		
	Windows 7 Professional 64	√	√
	Windows 7 Home Basic 64	√	√
	Windows 7 Home Premium 64	√	√
	DRDVD Windows 7	√	√
	Windows 8 Pro 64	√	√
	DRDVD Windows 8	√	√
	Web-only support:		
	Windows XP Professional	√	√
	Windows 7 Home Basic 32	√	√
	Windows 7 Home Premium 32	√	√
	Windows 7 Professional 32	√	√
	Certified:		
	Microsoft WHQL	√	√
	SuSE Linux Enterprise (SLED) SP2 64 bit	√	√
Serviceability	End-user replaceable parts:		
	AC adapter	√	√
	Battery (system)	√	√
	Hard drive	√	√

Category	Description	4445s (UMA)	4446s (disc)
	Optical drive	√	√
	Memory module	√	√
	WLAN module	√	√
	Keyboard	√	√

2 External Component Identification

Top


TouchPad



Component	Description
(1) TouchPad on/off button	Turns the TouchPad on and off.
(2) TouchPad zone	Moves the pointer and selects or activates items on the screen.
(3) Left TouchPad button	Functions like the left button on an external mouse.
(4) Right TouchPad button	Functions like the right button on an external mouse.

Lights


 **NOTE:** Refer to the illustration that most closely matches your computer.



Component	Description
(1)  Power light	<ul style="list-style-type: none">• On: The computer is on.• Blinking: The computer is in the Sleep/Suspend state, which is an energy-saving mode. The computer shuts off power to the display and other unneeded components.• Off: The computer is off or in Hibernation. Hibernation is an energy-saving mode that uses the least amount of power.
(2) Caps lock light	On: Caps lock is on.
(3)  Web browser light	<ul style="list-style-type: none">• On: The computer is on.• Off: The computer is off, in the Suspend state, or in Hibernation. Hibernation is an energy-saving mode that uses the least amount of power.
(4)  Wireless light	<ul style="list-style-type: none">• White: An integrated wireless device, such as a wireless local area network (WLAN) device and/or a Bluetooth® device, is on.• Amber: All wireless devices are off.
(5) TouchPad light	<ul style="list-style-type: none">• Amber: The TouchPad is off.• Off: The TouchPad is on.

Buttons, speakers, and fingerprint reader (select models only)


 **NOTE:** Refer to the illustration that most closely matches your computer.



Component	Description
(1)  Power button	<ul style="list-style-type: none"> • When the computer is off, press the button to turn on the computer. • When the computer is on, press the button briefly to initiate Sleep/Suspend. • When the computer is in the Sleep/Suspend state, press the button briefly to exit Sleep/Suspend. • When the computer is in Hibernation, press the button down briefly to exit Hibernation. <p>If the computer has stopped responding and the operating system shutdown procedures are ineffective, press and hold the power button down for at least 5 seconds to turn off the computer.</p> <p>CAUTION: Pressing and holding down the power button will result in the loss of unsaved information.</p> <p>To learn more about your power settings:</p> <p>In Windows 7:</p> <ol style="list-style-type: none"> 1. Select Computer > Control Center. 2. In the left pane, click System, and then click Power Management in the right pane. <p>In Windows 8:</p> <p>From the Start screen, type <code>power options</code>. Click Settings, and then select Power Options from the options displayed.</p> <p>In SUSE Linux:</p> <ol style="list-style-type: none"> 1. Select Computer > Control Center. 2. In the left pane, click System, and then click Power Management in the right pane.
(2) Speakers (2)	Produce sound.
(3)  Web browser button	Opens the default Web browser.
(4)  Wireless button	<p>Turns the wireless feature on or off but does not establish a wireless connection.</p> <p>NOTE: A wireless connection may be established if one has been previously configured.</p>
(5) Fingerprint reader (select models only)	Allows a fingerprint logon to the operating system, instead of a password logon.


Keys - Windows models

 **NOTE:** Refer to the illustration that most closely matches your computer.




Component	Description
(1) esc key	Displays system information when pressed in combination with the fn key.
(2) fn key	Executes frequently used system functions when pressed in combination with a function key, the num lk key or the esc key.
(3)  Windows 7 logo key	Displays the Windows Start screen.
 Windows 8 logo key	
(4) Function keys	Execute frequently used system functions when pressed in combination with the fn key.
(5) Embedded numeric keypad	When the keypad is turned on, it can be used like an external numeric keypad. Each key on the keypad performs the function indicated by the icon in the upper-right corner of the key.
(6)  Windows applications key	Windows 7: Displays a shortcut menu for items beneath the cursor. Windows 8: Displays a shortcut menu for items beneath the cursor. Displays the Apps bar.
(7) num lk key	Turns the embedded numeric keypad on and off. NOTE: The keypad function that is active when the computer is turned off is reinstated when the computer is turned back on.

Keys - SUSE Linux models




Component		Description
(1)	fn key	Executes frequently used system functions when pressed in combination with a function key.
(2)	 Operating system logo key	Displays the operating system menu.
(3)	Function keys	Execute frequently used system functions when pressed in combination with the fn key.
(4)	Embedded numeric keypad	Can be used like an external numeric keypad when pressed in combination with the fn and num lk keys..
		Each key on the keypad performs the function indicated by the icon in the upper-right corner of the key.
(5)	 Operating system applications key	Displays a shortcut menu for items beneath the cursor.
(6)	num lk key	Turns the embedded numeric keypad on and off when pressed in combination with the fn key.
		NOTE: The keypad function that is active when the computer is turned off is reinstated when the computer is turned back on.

Front




Component	Description
(1)  Hard drive light	<ul style="list-style-type: none"> • Blinking White: The hard drive is being accessed. • Amber: HP 3D DriveGuard has temporarily parked the hard drive.
(2) Media Card Reader	<p>Supports the following digital card formats:</p> <ul style="list-style-type: none"> • Memory Stick Pro • Memory Stick Duo Pro (needs an adapter) • MultiMediaCard (MMC) • MultiMediaCardplus (MMC+) • Secure Digital (SD) Card • Secure Digital High Capacity (SDHC) Card • Secure Digital Extra Capacity (SDXC) Card
(3)  Audio-out (headphone) jack	<p>Produces sound when connected to optional powered stereo speakers, headphones, earbuds, a headset, or television audio.</p> <p>WARNING! To reduce the risk of personal injury, adjust the volume before putting on headphones, earbuds, or a headset. For additional safety information, refer to the <i>Regulatory, Safety, and Environmental Notices</i>.</p> <p>In Windows 8:</p> <p>To access this guide, select the HP Support Assistant app on the Start screen, select My computer, and then select the User guides.</p> <p>NOTE: When a device is connected to the jack, the computer speakers are disabled.</p>
(4)  Audio-in (microphone) jack	<p>Connects an optional computer headset microphone, stereo array microphone, or monaural microphone.</p>

Right



Component	Description
(1)  USB 2.0 ports (2)	Connect optional USB devices.
(2) Optical drive (select models only)	Reads to an optical disc. NOTE: On select models, the optical drive also writes to an optical disc.
(3) Optical drive light (select models only)	<ul style="list-style-type: none"> On: The optical drive is being accessed. Off: The optical drive is idle.
(4) Optical drive eject button (select models only)	Releases the optical drive disc tray.

Left




Component	Description
(1)  Security cable slot	Attaches an optional security cable to the computer. NOTE: The security cable is designed to act as a deterrent, but it may not prevent the computer from being mishandled or stolen.
(2) Power connector	Connects an AC adapter.

Component		Description
(3)	 AC adapter/battery light	<ul style="list-style-type: none"> Amber: The computer is connected to external power and the battery is charged from 0 to 90 percent. White: The computer is connected to external power and the battery is charged from 90 to 99 percent. Blinking amber: A battery that is the only available power source has reached a low battery level. When the battery reaches a critical battery level, the AC adapter/battery light begins blinking rapidly. Off: The battery is fully charged.
(4)	Vent	Enables airflow to cool internal components. NOTE: The computer fan starts up automatically to cool internal components and prevent overheating. It is normal for the internal fan to cycle on and off during routine operation.
(5)	 External monitor port	Connects an external VGA monitor or projector.
(6)	 RJ-45 (network) jack	Connects a network cable.
(7)	 HDMI port	Connects an optional video or audio device, such as a high-definition television, or any compatible digital or audio device.
(8)	 USB 3.0 ports (2)	Connect optional USB devices.

Display

 **NOTE:** Refer to the illustration that most closely matches your computer.




Component	Description
(1) WLAN antennas (2)*	Send and receive wireless signals to communicate with wireless local area networks (WLAN).
(2) Internal microphone(s) (1 or 2 depending on model)	Record sound.
(3) Webcam light (select models only)	On: The webcam is in use.
(4) Webcam (select models only)	Records video and captures still photographs. To use the webcam to access Help and Support in Windows 7 select Start > All Programs > Music, Photos, and Videos > WebCam Companion . To use the webcam to access Help and Support in Windows 8, from the Start screen, type <code>help</code> , and then select Help and Support .
(5) Internal display switch	Turns off the display or initiates Sleep if the display is closed while the power is on. NOTE: The display switch is not visible from the outside of the computer.

*The antennas are not visible on the outside of the computer. For optimal transmission, keep the areas immediately around the antennas free from obstructions. To see wireless regulatory notices, see the section of the *Regulatory, Safety, and Environmental Notices* that applies to your country or region. These notices are located in Help and Support. To access this guide in Windows 8, select the **HP Support Assistant** app on the Start screen, select **My computer**, and then select the **User guides**.

Bottom

 **NOTE:** Your computer may look slightly different from the illustration in this section.




Component	Description
(1)  	<p>Battery and service door release latches</p> <ul style="list-style-type: none">• Release the battery from the battery bay by sliding the release latches one time.• When the battery has been removed from the battery bay, release the service door from the computer by sliding the release latches a second time.
(2)	<p>Battery bay</p> <p>Holds the battery.</p>

Component	Description
(3)  Service door	<p>Protects the hard drive bay, the wireless LAN (WLAN) module slot, and the memory module slots.</p> <p>CAUTION: To prevent an unresponsive system, replace the wireless module only with a wireless module authorized for use in the computer by the governmental agency that regulates wireless devices in your country or region. If you replace the module and then receive a warning message, remove the module to restore computer functionality, and then contact support through Help and Support.</p> <p>On Windows 7 models, contact technical support through Help and Support.</p> <p>On Windows 8 models, From the Start screen, type <code>help</code>, and then select Help and Support</p> <p>On SUSE Linux models, contact technical support through Linux Help.</p>
(4) Vents (2)	<p>Enable airflow to cool internal components.</p> <p>NOTE: The computer fan starts up automatically to cool internal components and prevent overheating. It is normal for the internal fan to cycle on and off during routine operation.</p>

Identifying the bottom parts of the computer

 **NOTE:** The service door has been removed in the following illustration.




Component	Description
(1) 	Memory modules
(2) 	Hard drive
(3) 	WLAN module slot (select models only)

3 Illustrated parts catalog

Service tag

When ordering parts or requesting information, provide the computer serial number and model description provided on the service tag.




- Product name **(1)**. This is the product name affixed to the front of the computer.
- Serial number (s/n) **(2)**. This is an alphanumeric identifier that is unique to each product.
- Part number/Product number (p/n) **(3)**. This number provides specific information about the product's hardware components. The part number helps a service technician to determine what components and parts are needed.
- Warranty period **(4)**. This number describes the duration (in years) of the warranty period for the computer.
- Model description **(5)**. This is the alphanumeric identifier used to locate documents, drivers, and support for the computer.

PCID Label


The PCID label provides the information required to properly reset the notebook firmware (BIOS) back to factory shipped specifications when replacing the system board. The following image illustrates label location.

 **NOTE:** Computer layout may vary between models.


The PCID label used on Windows 7 and SUSE Linux models is shown below.



The PCID label used on Windows 8 models is shown below.




Computer major components



Item	Description	Spare part number
(1)	Display panel	
	35.6-cm (14.0-inch), anti-glare, without webcam	683785-001
	35.6-cm (14.0-inch), anti-glare, with webcam	683786-001
	35.6-cm (14.0-inch), BrightView, without webcam	683787-001
	35.6-cm (14.0-inch), BrightView, with webcam	683788-001
(2)	Keyboard (includes cable)	
	For use in models using Windows 7 NOTE: For a detailed list of available keyboards, see Sequential part number listing on page 29 .	683657-xxx
	For use in models using Windows 8 NOTE: For a detailed list of available keyboards, see Sequential part number listing on page 29 .	702238-xxx
(3)	Top cover	
	For use in models with a fingerprint reader	683666-001
	For use In models without a fingerprint reader	683667-001
(4)	Audio board	683475-001
(5)	RTC battery	683601-001
(6)	Power/function board	683653-001
(7)	Fingerprint reader module with cable, bracket, and screw	683652-001
(8)	System board (includes RTC battery, and replacement thermal grease for CPU and thermal pad for VGA)	
	System board for use UMA models with Windows 7	683600-001
	System board for use in UMA models with Windows 8 Std	683600-501
	System board for use in UMA models with Windows 8 Pro	683600-601
	System board for use in discrete models with 1-GB graphics memory and Windows 7	683598-001
	System board for use in discrete models with 1-GB graphics memory and Windows 8 Std	683598-501
	System board for use in discrete models with 1-GB graphics memory and Windows 8 Pro	683598-601
	System board for use in discrete models with 2-GB graphics memory with Windows 7	683599-001
	System board for use in discrete models with 2-GB graphics memory and Windows 8 Std	683599-501
	System board for use in discrete models with 2-GB graphics memory and Windows 8 Pro	683599-601
(9)	Speaker assembly	683665-001
(10)	Metal heat shield	683497-001
(11)	Battery, Li-ion	
	9-cell (93 WHr, 2.8 Ah)	633809-001
	6-cell (47 WHr, 2.2 Ah)	633805-001
(12)	Base enclosure	683639-001

Item	Description	Spare part number
(13)	WLAN module	
	Atheros 9485GN 802.11b/g/n 1x1 WiFi and 3012 Bluetooth 4.0 Combo Adapter	655795-001
	Atheros AR9485 802.11 b/g/n WiFi Adapter	675794-001
	Atheros AR9462 802.11 a/b/g/n 2x2 BT4.0 Combo	676786-001
	Atheros AR9565 802.11 b/g/n 1x1 WiFi + BT4.0 Combo Adapter	690019-001
	Broadcom 4313GN 802.11b/g/n 1x1 WiFi and 20702 Bluetooth 4.0 Combo Adapter	657325-001
	Ralink RT5390F 802.11b/g/n 1x1 PCIe C	670691-001
	Ralink RT3290LE 802.11 b/g/n 1x1 WiFi and Bluetooth 4.0 Combo Adapter	690020-001
	Ralink RT5390R 802.11 b/g/n 1x1 WiFi Adapter	691415-001
(14)	USB module with cable (part of Cable kit, spares #683640-001)	
(15)	Memory modules (PC3-12800, 1600-MHz, DDR3)	
	4-GB	641369-001
	2-GB	652972-001
(16)	Optical drive (includes bracket, bezel, and screws)	
	Blu-ray ROM DVD±RW SuperMulti DL Drive	691110-001
	DVD± RW Double Layer Drive	691111-001
(17)	Processor (includes thermal material)	
	AMD A4-4300M (3.0-GHz/2.5-GHz, 1-MB L2 cache)	685990-001
	AMD A6-4400M (3.2-GHz/2.7-GHz, 1-MB L2 cache)	683047-001
	AMD A8-4500M (2.8-GHz/1.9-GHz, 4-MB L2 cache)	683048-001
(18)	Hard drive	
	750-GB, 7200-rpm (2.5 in)	633252-001
	750-GB, 5400 rpm (2.5 in)	634250-001
	640-GB, 5400-rpm (2.5 in)	669300-001
	500-GB, 7200 rpm (2.5 in)	634925-001
	500-GB, 5400 rpm (2.5 in)	669299-001
	320-GB, 7200-rpm (2.5 in)	641672-001
	320-GB, 5400 rpm (2.5 in)	622643-001
(19)	Heat sink (includes replacement thermal material)	
	For use in models with discrete graphics	683783-001
	For use in models with UMA graphics	683784-001
(20)	Fan	683651-001
(21)	Bottom door	690979-001

Display components




Item	Description	Spare part number
(1)	Display hinge cover included in Display hinge kit spare part number 683463-001	
(2)	Display bezel includes LCD rubbers	
	For use with models with a webcam	683641-001
	For use with models without a webcam	683642-001
(3)	Webcam module	683508-001
	Microphone module (not illustrated)	647675-001
(4)	Display hinges (includes left and right hinges, and covers)	683643-001
	Hinge cover included in Display hinge kit spare part number 683463-001	

Plastics Kit



Item	Description	Spare part number
	Plastics Kit	683662-001
(1)	Optical drive protective insert	
(2)	Secure Digital card protective insert	

Cable Kit



Item	Description	Spare part number
	Cable Kit:	683640-001
(1)	Battery connector cable	
(2)	Power connector cable	
(3)	Audio cable	
(4)	USB module with cable	

Mass storage devices

Description	Spare part number
Optical drives	
Blu-ray BD-R/RE DVD±RW SuperMulti DL Drive	691110-001
DVD-ROM Drive	691111-001
Hard drives	
750-GB, 7200 rpm (2.5 in)	633252-001
750-GB, 5400 rpm (2.5 in)	634250-001
640-GB, 5400 rpm (2.5 in)	669300-001
500-GB, 7200 rpm (2.5 in)	634925-001
500-GB, 5400 rpm (2.5 in)	669299-001
320-GB, 7200 rpm (2.5 in)	641672-001
320-GB, 5400 rpm (2.5 in)	622643-001
Hard Drive Hardware Kit (includes hard drive bracket, mylar insulator, and screws)	683488-001

Miscellaneous parts

Description	Spare part number
AC adapters	
65-W AC smart adapter, RC/V EM PFC	693710-001
65-W AC smart adapter, non-PFC	693711-001
90-W AC smart adapter, PFC	693712-001
90-W AC smart adapter, EM PFC	693713-001
Power cord for use in the United States	490371-001
Power cord for use in the United Kingdom/Singapore	490371-031
Power cord for use in Thailand	490371-201
Rubber Kit	683663-001
Screw Kit	683664-001
Mouse , optical, 2-button	390632-001
HP optical travel mouse	434594-001
HP essential top load case	679921-001
Professional slim, top load case	592923-001
Nylon case	612757-001

Description	Spare part number
Notebook combination lock	591699-001
HP keyed cable lock	626729-001

Sequential part number listing

CSR flag designations:

A = Mandatory

B = Optional

C = Service technician recommended

N = Non-user replaceable

Spare part number	CSR flag	Description
390632-001	A	Mouse, optical, 2-button
434594-001	A	HP optical travel mouse
490371-001	A	Power cord for use in the United States
490371-031	A	Power cord for use in the United Kingdom/Singapore
490371-201	A	Power cord for use in Thailand
591699-001	A	Notebook combination lock
592923-001	A	Professional slim, top load case
612757-001	A	Nylon case
622643-001	A	320-GB, 5400-rpm hard drive
626729-001	A	HP keyed cable lock
633252-001	A	750-GB, 7200-rpm hard drive (2.5 in)
633805-001	A	6-cell, 47 WHr, 2.2 Ah Li-ion battery
633809-001	A	9-cell, 93 WHr, 2.8 Ah Li-ion battery
634250-001	A	750-GB, 5400 rpm hard drive (2.5 in)
634925-001	A	500-GB, 7200 rpm hard drive (2.5 in)
641369-001	A	4-GB memory module (PC3-12800, 1600-MHz, DDR3)
641672-001	A	320-GB, 7200-rpm hard drive (2.5 in)
647675-001	N	Microphone module
652972-001	A	2-GB memory module (PC3-12800, 1600-MHz, DDR3)
655795-001	A	Atheros 9485GN 802.11b/g/n 1x1 WiFi and 3012 Bluetooth 4.0 Combo Adapter
657325-001	A	Broadcom 4313GN 802.11b/g/n 1x1 WiFi and 20702 Bluetooth 4.0 Combo Adapter
669299-001	A	500-GB, 5400-rpm hard drive (2.5 in)

Spare part number	CSR flag	Description
669300-001	A	640-GB, 5400-rpm hard drive (2.5 in)
670691-001	A	Ralink RT5390F 802.11b/g/n 1x1 PCIe HMC
675794-001	A	Atheros AR9585 802.11b/g/n WiFi Adapter
676786-001	A	Atheros AR 802.11 a/9462 a/b/g/n 2x2 BT4.0 combo
679921-001	A	HP essential top load case
683047-001	N	AMD processor A6-4400M (3.2-GHz/2.7-GHz, 1-MB L2 cache)
683048-001	N	AMD processor A8-4500M (2.8-GHz/1.9-GHz, 4-MB L2 cache)
683475-001	N	Audio board
683488-001	A	Hard drive hardware kit (includes hard drive bracket, mylar insulator, and screws)
683497-001	N	Metal heat shield
683508-001	N	Webcam
683598-001	N	System board for use in models with 1-GB of discrete memory and Windows 7
683598-501	N	System board for use in models with 1-GB of discrete memory and Windows 8 Std
683598-601	N	System board for use in models with 1-GB of discrete memory and Windows 8 Pro
683599-001	N	System board for use in models with 2-GB of discrete memory and Windows 7
683599-501	N	System board for use in models with 2-GB of discrete memory and Windows 8 Std
683599-601	N	System board for use in models with 2-GB of discrete memory and Windows 8 Pro
683600-001	N	System board for use in models with UMA graphics with Windows 7
683600-501	N	System board for use in models with UMA graphics and Windows 8 Std
683600-601	N	System board for use in models with UMA graphics and Windows 8 Pro
683601-001	N	RTC battery
683639-001	N	Base enclosure
683640-001	N	Cable kit
683641-001	N	Display bezel with webcam
683642-001	N	Display bezel without webcam
683643-001	N	Display hinges
683651-001	N	Fan
683652-001	N	Fingerprint module with cable, includes bracket with screws
683653-001	N	Power/function boards with cable
683657-001	A	Keyboard with TouchPad for use in the United States
683657-281	A	Keyboard with TouchPad for use in Thailand
683657-291	A	Keyboard with TouchPad for use in Japan
683657-AB1	A	Keyboard with TouchPad for use in Taiwan
683657-AD1	A	Keyboard with TouchPad for use in South Korea

Spare part number	CSR flag	Description
683657-D61	A	Keyboard with TouchPad for use in India
683662-001	A	Plastics kit, includes ODD dummy, and SD dummy
683663-001	N	Rubber kit, includes 5 ea LCD rubbers and lower case rubbers
683664-001	N	Screw kit, includes 15 ea all screws
683665-001	N	Speaker
683666-001	N	Top cover with Fingerprint reader, includes TouchPad assy with cable, ESD board and screws
683667-001	N	Top cover without fingerprint reader, includes TouchPad assy with cable, ESD board and screws, and fingerprint bracket with dummy and screws
683783-001	N	Heat sink for use with models with discrete graphics
683784-001	N	Heat sink for use with models with UMA graphics
683785-001	N	Hinge-up display Anti glare without webcam
683786-001	N	Hinge-up display Anti glare with webcam
683787-001	N	Hinge-up display Bright Vies without webcam
683788-001	N	Hinge-up display Bright Vies with webcam
685990-001	N	AMD processor A4-4300 M (3.0-GHz/2.5-GHz, 1-MB L2 cache)
690019-001	A	Atheros AR9565 802.11 b/g/n 1x1 WiFi + BT4.0 combo Adapter
690020-001	A	Ralink RT3290LE 802.11 b/g/n 1x1 WiFi and Bluetooth 4.0 Combo Adapter
690979-001	A	Bottom door
691110-001	A	Blu-ray BD-R/RE DVD±RW SuperMulti DL Drive
691111-001	A	DVD-ROM Drive
691415-001	A	Ralink R5390R 802.11 b/g/n 1x1 WiFi Adapter
693710-001	A	65-W smart adapter, RC/V EM
693711-001	A	65-W non-PFC adapter
693712-001	A	90-W smart PFC adapter
693713-001	A	90-W smart PFC adapter, EM
702238-001	A	Keyboard with TouchPad for use with Windows 8 in the United States
702238-281	A	Keyboard with TouchPad for use with Windows 8 in Thailand
702238-291	A	Keyboard with TouchPad for use with Windows 8 in Japan
702238-AB1	A	Keyboard with TouchPad for use with Windows 8 in Taiwan
702238-AD1	A	Keyboard with TouchPad for use with Windows 8 in South Korea
702238-D61	A	Keyboard with TouchPad for use with Windows 8 in India

4 Removal and replacement procedures

Preliminary replacement requirements

Tools required

You will need the following tools to complete the removal and replacement procedures:

- Flat-bladed screwdriver
- Phillips P0 and P1 screwdrivers
- Torx T8 screwdriver

Service considerations

The following sections include some of the considerations that you must keep in mind during disassembly and assembly procedures.



NOTE: As you remove each subassembly from the computer, place the subassembly (and all accompanying screws) away from the work area to prevent damage.

Plastic parts



CAUTION: Using excessive force during disassembly and reassembly can damage plastic parts. Use care when handling the plastic parts. Apply pressure only at the points designated in the maintenance instructions.

Cables and connectors

⚠ CAUTION: When servicing the computer, be sure that cables are placed in their proper locations during the reassembly process. Improper cable placement can damage the computer.

Cables must be handled with extreme care to avoid damage. Apply only the tension required to unseat or seat the cables during removal and insertion. Handle cables by the connector whenever possible. In all cases, avoid bending, twisting, or tearing cables. Be sure that cables are routed in such a way that they cannot be caught or snagged by parts being removed or replaced. Handle flex cables with extreme care; these cables tear easily.

Drive handling

⚠ CAUTION: Drives are fragile components that must be handled with care. To prevent damage to the computer, damage to a drive, or loss of information, observe these precautions:

Before removing or inserting a hard drive, shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.

Before handling a drive, be sure that you are discharged of static electricity. While handling a drive, avoid touching the connector.

Before removing a diskette drive or optical drive, be sure that a diskette or disc is not in the drive and be sure that the optical drive tray is closed.

Handle drives on surfaces covered with at least one inch of shock-proof foam.

Avoid dropping drives from any height onto any surface.

After removing a hard drive, an optical drive, or a diskette drive, place it in a static-proof bag.

Avoid exposing a hard drive to products that have magnetic fields, such as monitors or speakers.

Avoid exposing a drive to temperature extremes or liquids.

If a drive must be mailed, place the drive in a bubble pack mailer or other suitable form of protective packaging and label the package "FRAGILE."

Grounding guidelines

Electrostatic discharge damage

Electronic components are sensitive to electrostatic discharge (ESD). Circuitry design and structure determine the degree of sensitivity. Networks built into many integrated circuits provide some protection, but in many cases, ESD contains enough power to alter device parameters or melt silicon junctions.

A discharge of static electricity from a finger or other conductor can destroy static-sensitive devices or microcircuitry. Even if the spark is neither felt nor heard, damage may have occurred.

An electronic device exposed to ESD may not be affected at all and can work perfectly throughout a normal cycle. Or the device may function normally for a while, and then degrade in the internal layers, reducing its life expectancy.

⚠ CAUTION: To prevent damage to the computer when you are removing or installing internal components, observe these precautions:

Keep components in their electrostatic-safe containers until you are ready to install them.

Use nonmagnetic tools.

Before touching an electronic component, discharge static electricity by using the guidelines described in this section.

Avoid touching pins, leads, and circuitry. Handle electronic components as little as possible.

If you remove a component, place it in an electrostatic-safe container.

The following table shows how humidity affects the electrostatic voltage levels generated by different activities.

⚠ CAUTION: A product can be degraded by as little as 700 V.

Typical electrostatic voltage levels			
Event	Relative humidity		
	10%	40%	55%
Walking across carpet	35,000 V	15,000 V	7,500 V
Walking across vinyl floor	12,000 V	5,000 V	3,000 V
Motions of bench worker	6,000 V	800 V	400 V
Removing DIPS from plastic tube	2,000 V	700 V	400 V
Removing DIPS from vinyl tray	11,500 V	4,000 V	2,000 V
Removing DIPS from Styrofoam	14,500 V	5,000 V	3,500 V
Removing bubble pack from PCB	26,500 V	20,000 V	7,000 V
Packing PCBs in foam-lined box	21,000 V	11,000 V	5,000 V

Packaging and transporting guidelines

Follow these grounding guidelines when packaging and transporting equipment:

- To avoid hand contact, transport products in static-safe tubes, bags, or boxes.
- Protect ESD-sensitive parts and assemblies with conductive or approved containers or packaging.
- Keep ESD-sensitive parts in their containers until the parts arrive at static-free workstations.
- Place items on a grounded surface before removing items from their containers.
- Always be properly grounded when touching a component or assembly.
- Store reusable ESD-sensitive parts from assemblies in protective packaging or nonconductive foam.
- Use transporters and conveyors made of antistatic belts and roller bushings. Be sure that mechanized equipment used for moving materials is wired to ground and that proper materials are selected to avoid static charging. When grounding is not possible, use an ionizer to dissipate electric charges.

Workstation guidelines

Follow these grounding workstation guidelines:

- Cover the workstation with approved static-shielding material.
- Use a wrist strap connected to a properly grounded work surface and use properly grounded tools and equipment.
- Use conductive field service tools, such as cutters, screwdrivers, and vacuums.
- When fixtures must directly contact dissipative surfaces, use fixtures made only of static-safe materials.
- Keep the work area free of nonconductive materials, such as ordinary plastic assembly aids and Styrofoam.
- Handle ESD-sensitive components, parts, and assemblies by the case or PCM laminate. Handle these items only at static-free workstations.
- Avoid contact with pins, leads, or circuitry.
- Turn off power and input signals before inserting or removing connectors or test equipment.

Equipment guidelines

Grounding equipment must include either a wrist strap or a foot strap at a grounded workstation.

- When seated, wear a wrist strap connected to a grounded system. Wrist straps are flexible straps with a minimum of one megohm $\pm 10\%$ resistance in the ground cords. To provide proper ground, wear a strap snugly against the skin at all times. On grounded mats with banana-plug connectors, use alligator clips to connect a wrist strap.
- When standing, use foot straps and a grounded floor mat. Foot straps (heel, toe, or boot straps) can be used at standing workstations and are compatible with most types of shoes or boots. On conductive floors or dissipative floor mats, use foot straps on both feet with a minimum of one megohm resistance between the operator and ground. To be effective, the conductive strips must be worn in contact with the skin.

The following grounding equipment is recommended to prevent electrostatic damage:

- Antistatic tapes
- Antistatic smocks, aprons, and sleeve protectors
- Conductive bins and other assembly or soldering aids
- Nonconductive foam
- Conductive tabletop workstations with ground cords of one megohm resistance
- Static-dissipative tables or floor mats with hard ties to the ground
- Field service kits
- Static awareness labels
- Material-handling packages
- Nonconductive plastic bags, tubes, or boxes
- Metal tote boxes
- Electrostatic voltage levels and protective materials

The following table lists the shielding protection provided by antistatic bags and floor mats.

Material	Use	Voltage protection level
Antistatic plastic	Bags	1,500 V
Carbon-loaded plastic	Floor mats	7,500 V
Metallized laminate	Floor mats	5,000 V


Component replacement procedures

This chapter provides removal and replacement procedures.

There are as many as 95 screws and screw locks, in 15 different sizes, that must be removed, replaced, or loosened when servicing the computer. Make special note of each screw and screw lock size and location during removal and replacement.

Service tag

When ordering parts or requesting information, provide the computer serial number and model description provided on the service tag.



- Product name **(1)**. This is the product name affixed to the front of the computer.
- Serial number (s/n) **(2)**. This is an alphanumeric identifier that is unique to each product.
- Part number/Product number (p/n) **(3)**. This number provides specific information about the product's hardware components. The part number helps a service technician to determine what components and parts are needed.
- Warranty period **(4)**. This number describes the duration (in years) of the warranty period for the computer.
- Model description **(5)**. This is the alphanumeric identifier used to locate documents, drivers, and support for the computer.

Battery


Description	Spare part number
9-cell, 93 WHr, 2.8 Ah Li-ion battery	633809-001
6-cell, 47 WHr, 2.2 Ah Li-ion battery	633805-001

Before disassembling the computer, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.

Remove the battery:

1. Position the computer upside-down on a flat surface, with the battery bay toward you.
2. Slide the battery release latches (1) to release the battery.
3. Pivot the battery (2) away from the computer and lift it up (3) to remove it.



Install the battery by inserting it into the battery bay until you hear a click.

Bottom door


Description	Spare part number
Bottom door	690979-001

Before disassembling the computer, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the battery (see [Battery on page 38](#)).

Remove the bottom door:

1. Position the computer upside-down on a flat surface, with the battery bay toward you.
2. Remove the locking screw (if installed) **(1)** and slide the release latches **(2)** in towards the center of the computer.
3. Slide the door toward the front of the computer **(3)**, and then lift the door off the computer **(4)**.



Reverse the removal procedures to install the bottom door.

Optical drive



NOTE: All optical drive spare part kits include an optical drive bezel.

Description	Spare part number
Blu-ray ROM DVD±RW SuperMulti DL Drive	691110-001
DVD±RW DL Drive	691111-001


Before removing the optical drive, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the battery (see [Battery on page 38](#)).
5. Remove the bottom door (see [Bottom door on page 39](#)).

Remove the optical drive:


1. Position the computer upside-down with the right side toward you.
2. Remove the Phillips PM2.5×6.0 screw **(1)** that secures the optical drive to the computer.
3. Push the optical drive tab **(2)** to release the optical drive from the computer.

4. Remove the optical drive **(3)** from the computer.



5. If it is necessary to replace the optical drive bracket, position the optical drive with the rear toward you.
6. Remove the two Phillips PM2.0×3.0 screws **(1)** that secure the optical drive bracket to the optical drive.

7. Remove the optical drive bracket (2).



Reverse this procedure to install an optical drive.

Hard drive



NOTE: All hard drive spare part kits include a hard drive bracket and screws.

Description	Spare part number
750-GB, 7200 rpm hard drive (2.5 in)	633252-001
750-GB, 5400 rpm hard drive (2.5 in)	634250-001
640-GB, 5400 rpm hard drive (2.5 in)	669300-001
500-GB, 7200 rpm hard drive (2.5 in)	634925-001
500-GB, 5400 rpm hard drive (2.5 in)	669299-001
320-GB, 7200 rpm hard drive (2.5 in)	641672-001
320-GB, 5400 rpm hard drive (2.5 in)	622643-001
Hard Drive Hardware Kit (includes hard drive bracket, mylar insulator, and screws)	683488-001


Before disassembling the computer, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the battery (see [Battery on page 38](#)).
5. Remove the bottom door (see [Bottom door on page 39](#)).

Remove the hard drive:


1. Position the computer upside-down, with the battery bay toward you.
2. Remove the four Phillips PM2.5×4.0 screws **(1)** that secure the hard drive to the computer.

3. Grasp the Mylar tab on the hard drive and slide the hard drive to the left **(2)** to disconnect it from the system board connector and remove the drive from the drive bay.



4. If it is necessary to replace the hard drive bracket, open the mylar protective cover **(1)** and remove the two Phillips PM3.0×3.0 hard drive bracket screws **(2)** from each side of the hard drive (4 total screws).

- Lift the bracket (3) straight up to remove it from the hard drive, and lower the mylar protective cover (4) from the drive.



Reverse this procedure to reassemble and install the hard drive.

Memory modules

NOTE: Primary and expansion memory is installed in a stacked configuration in the bottom of the computer.

Description	Spare part number
2-GB (PC3-12800, 1600-MHz, DDR3)	652972-001
4-GB (PC3-12800, 1600-MHz, DDR3)	641369-001

Update BIOS before adding memory modules

Before adding new memory, make sure you update the computer to the latest BIOS.

CAUTION: Failure to update the computer to the latest BIOS prior to installing new memory may result in various system problems.

To update BIOS:

- Navigate to www.hp.com.
- Click **Support & Drivers** > click **Drivers & Software**.
- In the **Enter a product name/number** box, type the computer model information, and then click **Search**.

4. Click the link for the computer model.
5. Select the operating system, and then click **Next**.
6. Under **Step 2: Select a Download**, click the **BIOS** link.
7. Click the link for the most recent BIOS.
8. Click the **Download** button, and then follow the on-screen instructions.


Before removing the memory module, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the battery (see [Battery on page 38](#)).
5. Remove the bottom door (see [Bottom door on page 39](#)).

Remove the memory module:

1. Position the computer upside-down with the battery bay toward you.
2. Spread the retaining tabs **(1)** on each side of the memory module slot to release the memory module. (The edge of the module opposite the slot rises away from the computer.)
3. Remove the memory module **(2)** by pulling the module away from the slot at an angle.

 **NOTE:** The computer uses two memory sockets. The top socket houses the expansion memory module and is shown in the following image. The bottom socket houses the primary memory module. The removal procedure is the same for both memory sockets.



Reverse this procedure to install a memory module.

WLAN/Bluetooth combo card

The computer uses a card that provides both WLAN and Bluetooth functionality.

Description	Spare part number
Atheros 9485GN 802.11b/g/n 1x1 WiFi and 3012 Bluetooth 4.0 Combo Adapter	655795-001
Atheros AR9485 802.11 b/g/n WiFi Adapter	675794-001
Atheros AR9565 802.11 b/g/n 1x1 WiFi + BT4.0 Combo Adapter	690019-001
Atheros AR9462 802.11 a/b/g/n 2x2 BT 4.0 Combo	676786-001
Broadcom 4313GN 802.11 b/g/n 1x1 WFI and 20702 Bluetooth Combo Adapter	657325-001
Ralink RT5390F 802.11 b/g/n PCIe HMC	670691-001
Ralink RT3290LE 802.11 b/g/n 1x1 WiFi and Bluetooth 4.0 Combo Adapter	690020-001
Ralink RT5390R 802.11 b/g/n 1x1 WiFi Adapter	691415-001

Before removing the WLAN module, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the battery (see [Battery on page 38](#)).
5. Remove the bottom door (see [Bottom door on page 39](#)).

Remove the WLAN module:


1. Position the computer right-side up with the battery bay toward you.
2. Disconnect the WLAN antenna cables **(1)** from the terminals on the WLAN module.

 **NOTE:** The WLAN antenna cable labeled “1” connects to the WLAN module “Main” terminal labeled “1”. The WLAN antenna cable labeled “2” connects to the WLAN module “Aux” terminal labeled “2”. If the computer is equipped with an 802.11a/b/g/n WLAN module, the yellow WLAN antenna cable connects to the middle terminal on the WLAN module.

3. Remove the two Phillips PM2.0×3.0 screws **(2)** that secure the WLAN module to the computer. (The edge of the module opposite the slot rises away from the computer.)

4. Remove the WLAN module (3) by pulling the module away from the slot at an angle.

 **NOTE:** WLAN modules are designed with a notch (4) to prevent incorrect insertion.



 **NOTE:** If the WLAN antennas are not connected to the terminals on the WLAN module, the protective sleeves must be installed on the antenna connectors, as shown in the following illustration.



Reverse this procedure to install the WLAN module.

Keyboard



NOTE: For a detailed list of available keyboards, see [Sequential part number listing on page 29](#).


Description	Spare part number
Keyboard for use in models using Windows 7	683657-xxx
Keyboard for use in models using Windows 8	702238-xxx

Before removing the keyboard, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the battery (see [Battery on page 38](#)).
5. Remove the bottom door (see [Bottom door on page 39](#)).
6. Remove the hard drive (see [Hard drive on page 43](#)).
7. Remove the memory (see [Memory modules on page 45](#)).

Remove the keyboard:

1. Position the computer upside-down with the front toward you.
2. Remove the two Phillips PM2.5×6.0 screw **(1)** that secure the keyboard to the computer.




3. Position the computer right-side up with the front toward you.
4. Open the computer as far as possible.
5. Grasp the keyboard and slide it towards the front of the computer **(1)** to release its catches.

6. Rotate the top of the keyboard up (2) to remove it from the unit and remove it (3) from the top cover..



7. Rotate the keyboard until it rests on the palm rest (1).
8. Lift the keyboard connector latch (2), and then disconnect the keyboard cable from the system board (3).



9. Remove the keyboard.

Reverse this procedure to install the keyboard.


Metal heat shield

Before removing the metal heat shield, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the battery (see [Battery on page 38](#)).
5. Remove the optical drive (see [Optical drive on page 40](#)).
6. Remove the bottom door (see [Bottom door on page 39](#)).
7. Remove the hard drive (see [Hard drive on page 43](#)).
8. Remove the memory (see [Memory modules on page 45](#)).
9. Remove the keyboard (see [Keyboard on page 49](#)).

Remove the Metal heat shield:

1. Position the computer upside-down with the battery bay away from you.
2. Remove the three Phillips screws (1) that secure the shield.
3. Rotate the shield up (2), then lift the shield out of the enclosure (3).



Reverse this procedure to install the metal heat shield.

Fan

Description	Spare part number
Fan	683651-001


Before removing the fan, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the following components:
 - a. Battery (see [Battery on page 38](#))
 - b. Bottom door (see [Bottom door on page 39](#)).
 - c. Hard drive (see [Hard drive on page 43](#))
 - d. Optical drive (see [Optical drive on page 40](#))
 - e. Memory (see [Memory modules on page 45](#))
 - f. WLAN module (see [WLAN/Bluetooth combo card on page 47](#))
 - g. Keyboard (see [Keyboard on page 49](#))
 - h. Metal heat shield (see [Metal heat shield on page 51](#))

Remove the fan:

1. Position the computer upside-down with the fan on the right.
2. Disconnect the fan cable **(1)** from the system board that secure the fan to the top cover.
3. Remove the two Phillips screws **(2)** that secure the fan to the top cover.

4. Lift the fan at an angle to remove it from the computer (3).



Reverse this procedure to install the fan.

 **NOTE:** To properly ventilate the computer, allow at least a 7.6-cm (3-in) clearance on the left side of the computer.

The computer uses an electric fan for ventilation. The fan is controlled by a temperature sensor and is designed to turn on automatically when high temperature conditions exist. These conditions are affected by high external temperatures, system power consumption, power management/battery conservation configurations, battery fast charging, and software requirements. Exhaust air is displaced through the ventilation grill located on the left side of the computer.

Top cover

Description	Spare part number
Top cover with TouchPad for use in models with a fingerprint reader	683666-001
Top cover with TouchPad for use in models without a fingerprint reader	683667-001


Before removing the top cover, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the following components:
 - a. Battery (see [Battery on page 38](#))
 - b. Bottom door (see [Bottom door on page 39](#)).


- c. Hard drive (see [Hard drive on page 43](#))
- d. Optical drive (see [Optical drive on page 40](#))
- e. Memory (see [Memory modules on page 45](#))
- f. WLAN module (see [WLAN/Bluetooth combo card on page 47](#))
- g. Keyboard (see [Keyboard on page 49](#))
- h. Metal heat shield (see [Metal heat shield on page 51](#))
- i. Fan (see [Fan on page 52](#))

Remove the top cover:


1. Position the computer upside-down with the front toward you.
2. Remove the following covers and screws that secure the top cover to the computer and disconnect the fan cable:
 - 4 rubber screw covers (1)
 - 9 Torx T8M2.5×6.0 screws (2)
 - 1 Phillips PM2.0x2.0 screw (3)




3. Remove the following screws that secure the top cover to the computer:
 - a. 3 Phillips PM2.0×3.0 screws (1) from the optical drive bay
 - b. 2 Phillips PM2.5×2.5 broadhead screws (2) from the battery bay



4. Remove the following cables from the system board:
 - (1): Power/function board cable
 - (2): Fingerprint reader cable




5. Remove 3 Torx T8M2.5x6 screws.




6. Position the computer on its side with the display open.


7. Insert a screwdriver through the holes in the battery bay and press to disengage the top cover from the computer.



8. Pull up on the top of the top cover (1), pull upward on the left (2) and right sides (3), and then lift the top cover (4) enough to gain access to the audio board cable underneath.



9. With the top cover at an angle (1), disconnect the audio board cable (2) from the system board, and then remove the top cover from the computer .



Reverse this procedure to install the top cover.

Audio board

Description	Spare part number
Audio board	683475-001


Before removing the audio board, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the following components:
 - a. Battery (see [Battery on page 38](#))
 - b. Bottom door (see [Bottom door on page 39](#)).
 - c. Hard drive (see [Hard drive on page 43](#))
 - d. Optical drive (see [Optical drive on page 40](#))
 - e. Memory (see [Memory modules on page 45](#))
 - f. WLAN module (see [WLAN/Bluetooth combo card on page 47](#))
 - g. Keyboard (see [Keyboard on page 49](#))
 - h. Metal heat shield (see [Metal heat shield on page 51](#))
 - i. Fan (see [Fan on page 52](#))
 - j. Top cover (see [Top cover on page 53](#))

Remove the audio board:

1. Position the top cover upside-down with the front toward you.
2. Disconnect the cable **(1)** from the audio board.
3. Remove the 2 Phillips PM2.0×3.0 screws **(2)** that secures the board to the top cover.

4. Rotate the board upward and remove it (3).



Reverse this procedure to install the audio board.

Fingerprint reader

Description	Spare part number
Fingerprint reader	683652-001


Before removing the fingerprint reader, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the following components:
 - a. Battery (see [Battery on page 38](#))
 - b. Bottom door (see [Bottom door on page 39](#)).
 - c. Hard drive (see [Hard drive on page 43](#))
 - d. Optical drive (see [Optical drive on page 40](#))
 - e. Memory (see [Memory modules on page 45](#))
 - f. WLAN module (see [WLAN/Bluetooth combo card on page 47](#))
 - g. Keyboard (see [Keyboard on page 49](#))
 - h. Metal heat shield (see [Metal heat shield on page 51](#))
 - i. Fan (see [Fan on page 52](#))
 - j. Top cover (see [Top cover on page 53](#))

Remove the fingerprint reader:

1. Position the top cover upside-down with the front toward you.
2. Remove the Phillips PM2.0×3.0 screw **(1)** that secures the device to the top cover.
3. Slide the fingerprint reader out of the retainer **(2)**.

4. Lift the retainer (3) from the top cover and then remove the fingerprint reader (4).



Reverse the procedure to install the fingerprint reader.

Reverse this procedure to install the card reader.

Power button/function button

Description	Spare part number
Power button/function button board	683653-001


Before removing the power button board, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the following components:
 - a. Battery (see [Battery on page 38](#)).
 - b. Bottom door (see [Bottom door on page 39](#)).
 - c. Hard drive (see [Hard drive on page 43](#))
 - d. Optical drive (see [Optical drive on page 40](#))

- e. Memory (see [Memory modules on page 45](#))
- f. WLAN module (see [WLAN/Bluetooth combo card on page 47](#))
- g. Keyboard (see [Keyboard on page 49](#))
- h. Metal heat shield (see [Metal heat shield on page 51](#))
- i. Fan (see [Fan on page 52](#))
- j. Top cover (see [Top cover on page 53](#))

Remove the power button and function button boards.

1. Position the top cover on its face with the front towards you.
2. Remove the single screw (1) from the power button board and from the function button board.
3. Lift the two boards (2) and (3) from the top cover and then peel the cable from the top cover.
- 4.



Reverse this procedure to install the power button and function boards.

USB Module

Description	Spare part number
USB module (part of spares kit)	683640-001


Before removing the USB module, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.

3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the following components:
 - a. Battery (see [Battery on page 38](#)).
 - b. Bottom door (see [Bottom door on page 39](#)).
 - c. Hard drive (see [Hard drive on page 43](#))
 - d. Optical drive (see [Optical drive on page 40](#))
 - e. Memory (see [Memory modules on page 45](#))
 - f. WLAN module (see [WLAN/Bluetooth combo card on page 47](#))
 - g. Keyboard (see [Keyboard on page 49](#))
 - h. Metal heat shield (see [Metal heat shield on page 51](#))
 - i. Fan (see [Fan on page 52](#))
 - j. Top cover (see [Top cover on page 53](#))

Remove the USB module.

1. Position the top cover in the normal upright position with the lid in the open position.
2. Disconnect the USB cable (1) from the system board.
3. Remove the cable (2) from the base enclosure.
4. Remove the 2 screws (3) that secure the USB module.
5. Lift the module (4) from the system board.



Reverse this procedure to install the USB module.

Speaker

Description	Spare part number
Speaker	683665-001


Before removing the speaker, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the following components:
 - a. Battery (see [Battery on page 38](#)).
 - b. Bottom door (see [Bottom door on page 39](#)).
 - c. Hard drive (see [Hard drive on page 43](#))
 - d. Optical drive (see [Optical drive on page 40](#))
 - e. Memory (see [Memory modules on page 45](#))
 - f. WLAN module (see [WLAN/Bluetooth combo card on page 47](#))
 - g. Keyboard (see [Keyboard on page 49](#))
 - h. Metal heat shield (see [Metal heat shield on page 51](#))
 - i. Fan (see [Fan on page 52](#))
 - j. Top cover (see [Top cover on page 53](#))

Remove the speaker.

1. Position the top cover in the normal upright position with the lid in the open position.
2. Disconnect the speaker cable **(1)** from the system board.
3. Remove the two screws **(2)** that secure the speaker.

- Lift the speaker (3) from the computer.



Reverse this procedure to install the speaker.

System board

 **NOTE:** All system board spare part kits include replacement thermal material.

Description	Spare part number
System boards for use in models without Windows 8:	
Shared video memory with UMA graphics	683600-001
2-GB of discrete graphics memory	683599-001
1-GB of discrete graphics memory	683598-001
System boards for use in Windows 8 models:	
Windows 8 Standard models with shared video memory with UMA graphics	683600-501
Windows 8 Professional models with shared video memory with UMA graphics	683600-601
Windows 8 Standard models with 2-GB of discrete graphics memory	683599-501
Windows 8 Professional models with 2-GB of discrete graphics memory	683599-601
Windows 8 Standard models with 1-GB of discrete graphics memory	683598-501
Windows 8 Professional models with 1-GB of discrete graphics memory	683598-601

Before removing the system board, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the following components:
 - a. Battery (see [Battery on page 38](#)).
 - b. Bottom door (see [Bottom door on page 39](#)).
 - c. Hard drive (see [Hard drive on page 43](#))
 - d. Optical drive (see [Optical drive on page 40](#))
 - e. Memory (see [Memory modules on page 45](#))
 - f. WLAN module (see [WLAN/Bluetooth combo card on page 47](#))
 - g. Keyboard (see [Keyboard on page 49](#))
 - h. Metal heat shield (see [Metal heat shield on page 51](#))
 - i. Fan (see [Fan on page 52](#))
 - j. Top cover (see [Top cover on page 53](#))


When replacing the system board, be sure to remove the following components from the defective system board and install on the replacement system board:

- Memory module (see [Memory modules on page 45](#))
- WLAN module (see [WLAN/Bluetooth combo card on page 47](#))
- Heat sink (see [Heat sink on page 69](#))
- Processor (see [Processor on page 72](#))


Remove the system board:

1. Position the computer upright with the front toward you.

2. Disconnect the main power cable (1), display cable (2), and the audio cable (3) from the system board.



3. Remove the two Phillips PM2.5×4.0 screws (1) that secure the system board then, lift the system board (2) to access the battery cable connector.



Remove the battery cable.

The battery cable is included in the Cable Kit, spare part number 683640-001.


1. With the system board at an angle, disconnect the battery cable (1) from the bottom of the board.



NOTE: The system board may now be safely removed.

2. Remove the two screws (2) that secure the connector to the base assembly.

3. Lift the connector (3) out of the unit.



Reverse this procedure to install the system board and the battery connector.

Heat sink

All heat sink spare part kits include replacement thermal material.

Description	Spare part number
Heat sink for use in computers with UMA graphics	683784-001
Heat sink for use in computers with discrete graphics	683783-001


Before removing the heat sink, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the following components:
 - a. Battery (see [Battery on page 38](#))
 - b. Bottom door (see [Bottom door on page 39](#)).
 - c. Hard drive (see [Hard drive on page 43](#))
 - d. Optical drive (see [Optical drive on page 40](#))
 - e. Memory (see [Memory modules on page 45](#))
 - f. WLAN module (see [WLAN/Bluetooth combo card on page 47](#))

- g. Keyboard (see [Keyboard on page 49](#))
- h. Metal heat shield (see [Metal heat shield on page 51](#))
- i. Fan (see [Fan on page 52](#))
- j. Top cover (see [Top cover on page 53](#))
- k. System board (see [System board on page 66](#))

Remove the discrete heat sink:


1. Position the system board face up with the front toward you.
2. To remove the discrete heat sink, in the order indicated on the heat sink, loosen the six captive Phillips screws (1) that secure the heat sink to the system board.
3. Lift the heat sink up (2), and then pull it off the system board (3).



Remove the UMA heat sink.


1. To remove the UMA heat sink, in the order indicated on the heat sink, loosen the four captive Phillips screws (1) that secure the heat sink to the system board.

2. Lift the heat sink up (2), and then pull it out of the computer (3).
Remove the UMA heat sink.




NOTE: For discrete models, thoroughly clean thermal material from the surfaces of the system board components (1) and (3) and the heat sink (2) and (4) each time you remove the heat sink. All heat sink and processor spare part kits include thermal material.

NOTE: When installing the heat sink, always tighten the screws in the order stamped on the components.



NOTE: For UMA models, thoroughly clean thermal material from the surface of the system board (1) and heat sink (2) each time you remove the heat sink. All heat sink and processor spare part kits include thermal material.

NOTE: When installing the heat sink, always tighten the screws in the order stamped on the components.



Reverse this procedure to install the heat sink.

Processor



NOTE: All processor spare part kits include replacement thermal material.

Description	Spare part number
AMD A4-4300M (3.0-GHz/2.5-GHz, 1-MB L2 cache)	685990-001
AMD A6-4400M (3.2-GHz/2.7-GHz, 1-MB L2 cache)	683047-001
AMD A8-4500M (2.8-GHz/1.9-GHz, 4-MB L2 cache)	683048-001

Before removing the processor, follow these steps:


1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the following components:
 - a. Battery (see [Battery on page 38](#))
 - b. Bottom door (see [Bottom door on page 39](#)).
 - c. Hard drive (see [Hard drive on page 43](#))
 - d. Optical drive (see [Optical drive on page 40](#))
 - e. Memory (see [Memory modules on page 45](#))
 - f. WLAN module (see [WLAN/Bluetooth combo card on page 47](#))
 - g. Keyboard (see [Keyboard on page 49](#))
 - h. Metal heat shield (see [Metal heat shield on page 51](#))
 - i. Fan (see [Fan on page 52](#))

- j. Top cover (see [Top cover on page 53](#))
- k. System board (see [System board on page 66](#))
- l. Heat sink (see [Heat sink on page 69](#))

Remove the processor:

1. Position the system board face up with the front toward you.
2. Use a flat-bladed screwdriver to turn the processor locking screw **(1)** one-half turn counterclockwise until you hear a click.
3. Lift the processor **(2)** straight up and remove it.

 **NOTE:** The gold triangle **(3)** on the processor must be aligned with the triangle **(4)** embossed on the processor slot when you install the processor.



Reverse this procedure to install the processor.

RTC battery

Description	Spare part number
RTC battery	683601-001


Before removing the RTC battery, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the following components:
 - a. Battery (see [Battery on page 38](#))
 - b. Bottom door (see [Bottom door on page 39](#)).
 - c. Hard drive (see [Hard drive on page 43](#))
 - d. Optical drive (see [Optical drive on page 40](#))
 - e. Memory (see [Memory modules on page 45](#))
 - f. WLAN module (see [WLAN/Bluetooth combo card on page 47](#))
 - g. Keyboard (see [Keyboard on page 49](#))
 - h. Metal heat shield (see [Metal heat shield on page 51](#))
 - i. Fan (see [Fan on page 52](#))
 - j. Top cover (see [Top cover on page 53](#))
 - k. System board (see [System board on page 66](#))

Remove the RTC battery:

1. Position the system board face up, with the front toward you.
2. Use a screwdriver to loosen the battery from the slot **(1)**.

3. Lift the battery from the system board (2).



Reverse this procedure to install the RTC battery.

Power cable


The power cable is included in the Cable Kit, spare part number 683640-001.

Before removing the power cable, follow these steps:

1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the following components:
 - a. Remove the battery (see [Battery on page 38](#))
 - b. Bottom door (see [Bottom door on page 39](#)).
 - c. Hard drive (see [Hard drive on page 43](#))
 - d. Optical drive (see [Optical drive on page 40](#))
 - e. WLAN module (see [WLAN/Bluetooth combo card on page 47](#))
 - f. Heat sink (see [Heat sink on page 69](#))
 - g. Keyboard (see [Keyboard on page 49](#))
 - h. Fan (see [Fan on page 52](#))
 - i. Top cover (see [Top cover on page 53](#))
 - j. System board (see [System board on page 66](#))

Remove the power cable:

1. Position the computer upright with the front toward you.
2. Disconnect the cable from the system board (1).
3. Lift the power cable assembly from the computer (2).



Reverse this procedure to install the power cable.

Display assembly

All display assemblies include WLAN antenna transceivers and cables.

For a list of individual display spare parts, see [Display components on page 25](#).


Description	Spare part number
35.6-cm (14.0-inch), Anti-glare, without webcam	683785-001
35.6-cm (14.0-inch), Anti-glare, with webcam	683786-001
35.6-cm (14.0-inch), BrightView, without webcam	683787-001
35.6-cm (14.0-inch), BrightView, with webcam	683788-001

Before removing the display assembly, follow these steps:


1. Shut down the computer. If you are unsure whether the computer is off or in Hibernation, turn the computer on, and then shut it down through the operating system.
2. Disconnect all external devices connected to the computer.
3. Disconnect the power from the computer by first unplugging the power cord from the AC outlet, and then unplugging the AC adapter from the computer.
4. Remove the following components:
 - a. Battery (see [Battery on page 38](#))
 - b. Bottom door (see [Bottom door on page 39](#)).
 - c. Hard drive (see [Hard drive on page 43](#))
 - d. Optical drive (see [Optical drive on page 40](#))
 - e. Memory (see [Memory modules on page 45](#))
 - f. WLAN module (see [WLAN/Bluetooth combo card on page 47](#))
 - g. Keyboard (see [Keyboard on page 49](#))
 - h. Metal heat shield (see [Metal heat shield on page 51](#))
 - i. Fan (see [Fan on page 52](#))
 - j. Top cover (see [Top cover on page 53](#))
 - k. System board (see [System board on page 66](#))

Remove the display assembly:

1. With the unit upside-down, remove the WLAN cables (1) from the raceway and the cable retainers (2).




2. Position the computer upright with the front toward you.
3. Open the computer as far as possible.
4. Remove the WLAN wires from the cable run (1) and the cable clips (2).



5. Remove the two Torx T8M2.5×6.0 screws (1) that secure the security bracket to the computer, and then lift the security bracket from the computer (2).
6. Remove the two Torx T8M2.5×6.0 screws (3) from the left hinge and the two Torx T8M2.5×6.0 screws (4) from the right hinge.

7. Lift the display assembly straight up and remove it (5).




⚠ CAUTION: When installing the display assembly, be sure that the wireless antenna cables are routed and arranged properly.


Failure to properly route the antennas can result in degradation of the computer's WLAN performance.

8. If you need to remove the hinge covers from the display hinges, pull the hinges straight up and off the display to remove them.

Display hinge covers are available in the Display hinge kit, spare part number 683643-001.



9. To replace the display bezel, remove the two rubber screw covers (1) and the two Phillips PM2.5×4.0 screws (2) in the bottom corners of the display bezel.
10. Flex the top (3) of the bezel, the inside edges of the left and right sides (4), and then the bottom (5) of the bezel until it disengages from the display enclosure.




11. Remove the display bezel.

The spare part number for the display bezel for webcam use is 683641-001.

The spare part number for the display bezel without webcam is 683642-001.

12. If it is necessary to replace the webcam module (shown in the following image) or microphone module from the display enclosure, disconnect the cable from the module **(1)**, and then gently pull the module away from the double-sided tape on the display enclosure **(2)**.

The webcam module is available using spare part number 683508-001.




 **NOTE:** The microphone module is removed using the same procedure and is available using spare part number 647675-001

13. If it is necessary to replace the display panel, remove the four Phillips PM2.5×4.0 screws **(1)** at the bottom and two Phillips PM2.5×4.0 broadhead screws **(2)** at the top that secure the panel to the display enclosure.
14. Rotate the top of the panel upward to remove it from the housing..


The display panel is available using the following spare part numbers:

- 646375-001: 35.6-cm (14.0-inch), Anti-glare
- 646989-001: 35.6-cm (14.0-inch), BrightView




15. Raise the enclosure (1) to access the cable connector.
16. Disconnect the display panel cable from the back of the display panel by lifting the tape over the connector (2), and then disconnecting the cable from the panel (3).

The display cable is available using spare part number 605766-001.



17. If it is necessary to replace the display hinges, remove the three Phillips PM2.0×3.0 screws (1) that secure each display hinge to the display panel.
18. Remove the display hinges (2).

Display hinges are available using spare part number 683643-001.



Reverse this procedure to reassemble and install the display assembly.

5 Computer Setup (BIOS) and Advanced System Diagnostics

Windows 7 – Computer Setup (BIOS) and Advanced System Diagnostics

Using Computer Setup

Computer Setup, or Basic Input/Output System (BIOS), controls communication between all the input and output devices on the system (such as disk drives, display, keyboard, mouse, and printer). Computer Setup includes settings for the types of devices installed, the startup sequence of the computer, and the amount of system and extended memory.

 **NOTE:** Use extreme care when making changes in Computer Setup. Errors can prevent the computer from operating properly.

Starting Computer Setup

 **NOTE:** An external keyboard or mouse connected to a USB port can be used with Computer Setup only if USB legacy support is enabled.

To start Computer Setup, follow these steps:

1. Turn on or restart the computer, and then press **esc** while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
2. Press **f10** to enter Computer Setup.

Navigating and selecting in Computer Setup

To navigate and select in Computer Setup, follow these steps:

1. Turn on or restart the computer, and then press **esc** while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
 - To select a menu or a menu item, use the **tab** key and the keyboard arrow keys and then press **enter**, or use a pointing device to click the item.
 - To scroll up and down, click the up arrow or the down arrow in the upper-right corner of the screen, or use the up arrow key or the down arrow key.
 - To close open dialog boxes and return to the main Computer Setup screen, press **esc**, and then follow the on-screen instructions.

 **NOTE:** You can use either a pointing device (TouchPad, pointing stick, or USB mouse) or the keyboard to navigate and make selections in Computer Setup.

2. Press **f10** to enter Computer Setup.

To exit Computer Setup menus, choose one of the following methods:

- To exit Computer Setup menus without saving your changes:
Click the **Exit** icon in the lower-left corner of the screen, and then follow the on-screen instructions.
– or –
Use the **tab** key and the arrow keys to select **File > Ignore Changes and Exit**, and then press **enter**.
- To save your changes and exit Computer Setup menus:
Click the **Save** icon in the lower-left corner of the screen, and then follow the on-screen instructions.
– or –
Use the **tab** key and the arrow keys to select **File > Save Changes and Exit**, and then press **enter**.

Your changes go into effect when the computer restarts.

Restoring factory settings in Computer Setup

 **NOTE:** Restoring defaults will not change the hard drive mode.

To return all settings in Computer Setup to the values that were set at the factory, follow these steps:

1. Turn on or restart the computer, and then press **esc** while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
2. Press **f10** to enter Computer Setup.
3. Use a pointing device or the arrow keys to select **File > Restore Defaults**.
4. Follow the on-screen instructions.
5. To save your changes and exit, click the **Save** icon in the lower-left corner of the screen, and then follow the on-screen instructions.

– or –

Use the arrow keys to select **File > Save Changes and Exit**, and then press **enter**.

Your changes go into effect when the computer restarts.

 **NOTE:** Your password settings and security settings are not changed when you restore the factory settings.

Updating the BIOS

The next sections describe different ways of updating the BIOS.

Downloading *SoftPaqs* to update the BIOS

Most BIOS updates on the HP website are packaged in compressed files called *SoftPaqs*.

To install BIOS updates from the HP website, follow the steps below:

1. Download the *SoftPaq* from the HP website.
2. Click **Run**, and then follow the on-screen instructions to update the BIOS.



NOTE: Some download packages contain a file named `Readme.txt`, which contains information regarding installing and troubleshooting the file.

BIOS management using system diagnostics

1. Download the *SoftPaq* from the HP website.



NOTE: Verify that the UEFI system diagnostics is installed on your computer (or USB flash drive).

2. Click **Run**, and then click **Cancel** at the Update/USB bootable dialog box.
3. Navigate to the folder located in `c:\swsetup` that corresponds to your *SoftPaq* number.
4. Locate the `.bin` file in the ROMpaq folder (for example, `68CDD.bin`) and then copy it to the Hewlett-Packard\BIOS\New\ folder in either the HP_Tools partition of the hard drive, or the USB flash drive.
5. Locate the `.sig` file in the ROM.cab file and rename it with the same prefix as the `.bin` file (for example, `68CDD.sig`). Copy the renamed file to the Hewlett-Packard\BIOS\New\ folder in either the HP_Tools partition of the hard drive, or the USB flash drive.
6. Restart the computer, and then press `esc` while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
7. Press `f2` to enter Computer Setup.
8. Click **BIOS Management** from the menu and then select **Update BIOS**.

Using `f10` setup to update the BIOS

1. Download the *SoftPaq* from the HP website.



NOTE: Verify that the UEFI system diagnostics is installed on your computer (or USB flash drive).

2. Click **Run**, and then click **Cancel** at the Update/USB bootable dialog box.
3. Navigate to the folder located in `c:\swsetup` that corresponds to your *SoftPaq* number.
4. Locate the `.bin` file in the ROMpaq folder (for example, `68CDD.bin`) and then copy it to the Hewlett-Packard\BIOS\New\ folder in either the HP_Tools partition of the hard drive, or the USB flash drive.
5. Locate the `.sig` file in the ROM.cab file and rename it with the same prefix as the `.bin` file (for example, `68CDD.sig`). Copy the renamed file to the Hewlett-Packard\BIOS\New\ folder in either the HP_Tools partition of the hard drive, or the USB flash drive.
6. Restart the computer, and then press `esc` while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
7. Press `f10` to enter Computer Setup.
8. Click **Update System BIOS**, and then click **Accept** to update the BIOS.

Determining the BIOS version

To determine whether available BIOS updates contain later BIOS versions than those currently installed on the computer, you need to know the version of the system BIOS currently installed.

BIOS version information (also known as *ROM date* and *System BIOS*) can be displayed by pressing **fn+esc** (if you are already in Windows) or by using Computer Setup.

1. Start Computer Setup.
2. Use a pointing device or the arrow keys to select **File > System Information**.
3. To exit Computer Setup without saving your changes, click the **Exit** icon in the lower-left corner of the screen, and then follow the on-screen instructions.

– or –

Use the **tab** key and the arrow keys to select **File > Ignore Changes and Exit**, and then press **enter**.

Downloading a BIOS update

 **CAUTION:** To reduce the risk of damage to the computer or an unsuccessful installation, download and install a BIOS update only when the computer is connected to reliable external power using the AC adapter. Do not download or install a BIOS update while the computer is running on battery power, docked in an optional docking device, or connected to an optional power source. During the download and installation, follow these instructions:

Do not disconnect power from the computer by unplugging the power cord from the AC outlet.

Do not shut down the computer or initiate Sleep or Hibernation.

Do not insert, remove, connect, or disconnect any device, cable, or cord.

1. Select **Start > Help and Support > Maintain**.
2. Follow the on-screen instructions to identify your computer and access the BIOS update you want to download.
3. At the download area, follow these steps:
 - a. Identify the BIOS update that is later than the BIOS version currently installed on your computer. Make a note of the date, name, or other identifier. You may need this information to locate the update later, after it has been downloaded to your hard drive.
 - b. Follow the on-screen instructions to download your selection to the hard drive.

Make a note of the path to the location on your hard drive where the BIOS update is downloaded. You will need to access this path when you are ready to install the update.

 **NOTE:** If you connect your computer to a network, consult the network administrator before installing any software updates, especially system BIOS updates.

BIOS installation procedures vary. Follow any instructions that are displayed on the screen after the download is complete. If no instructions are displayed, follow these steps:

1. Open Windows Explorer by selecting **Start > Computer**.
2. Double-click your hard drive designation. The hard drive designation is typically Local Disk (C:).
3. Using the hard drive path you recorded earlier, open the folder on your hard drive that contains the update.
4. Double-click the file that has an .exe extension (for example, *filename.exe*).
The BIOS installation begins.
5. Complete the installation by following the on-screen instructions.



NOTE: After a message on the screen reports a successful installation, you can delete the downloaded file from your hard drive.

BIOS Setup Menu

The tables in this section provide an overview of the BIOS Setup menu options.

Main menu

Select	To do this
System information	<ul style="list-style-type: none">• View and change the system time and date.• View identification information about your computer.• View specification information about the processor, memory size, and system BIOS.

Security menu

Select	To do this
Administrator password	Control access to Setup Utility.
Power-on password	Control access to your computer.

Diagnostics menu

Select	To do this
Primary Hard Disk Self Test	Run a quick or comprehensive self-test on the hard drive.
Memory Test	Run a diagnostic test on the system memory.

Using Advanced System Diagnostics

Advanced System Diagnostics allows you to run diagnostic tests to determine if the computer hardware is functioning properly. The following diagnostic tests are available in Advanced System Diagnostics:

- **Start-up test**—This test analyzes the main computer components that are required to start the computer.
- **Run-in test**—This test repeats the start-up test and checks for intermittent problems that the start-up test does not detect.
- **System Tune-Up**—This group of additional tests checks your computer to make sure that the main components are functioning correctly. System Tune-Up runs longer and more comprehensive tests on memory modules, hard drive SMART attributes, the hard drive surface, the battery (and battery calibration), video memory, and the WLAN module status.
- **Hard disk test**—This test analyzes the physical condition of the hard drive, and then checks all data in every sector of the hard drive. If the test detects a damaged sector, it attempts to move the data to a good sector.

- Memory test—This test analyzes the physical condition of the memory modules. If it reports an error, replace the memory modules immediately.
- Battery test—This test analyzes the condition of the battery and calibrates the battery if necessary. If the battery fails the test, contact support to report the issue and purchase a replacement battery.

You can view system information and error logs in the Advanced System Diagnostics window.

To start Advanced System Diagnostics:

1. Turn on or restart the computer. While the “Press the ESC key for Startup Menu” message is displayed in the lower-left corner of the screen, press **esc**. When the Startup Menu is displayed, press **f2**.
2. Click the diagnostic test you want to run, and then follow the on-screen instructions.



NOTE: If you need to stop a diagnostics test while it is running, press **esc**.

Windows 8 – Computer Setup (BIOS) and Advanced System Diagnostics

Using Computer Setup

Computer Setup, or Basic Input/Output System (BIOS), controls communication between all the input and output devices on the system (such as disk drives, display, keyboard, mouse, and printer). Computer Setup includes settings for the types of devices installed, the startup sequence of the computer, and the amount of system and extended memory.



NOTE: Use extreme care when making changes in Computer Setup. Errors can prevent the computer from operating properly.

Starting Computer Setup



NOTE: An external keyboard or mouse connected to a USB port can be used with Computer Setup only if USB legacy support is enabled.

To start Computer Setup, follow these steps:

1. Turn on or restart the computer, and then press **esc** while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
2. Press **f10** to enter Computer Setup.

Navigating and selecting in Computer Setup

To navigate and select in Computer Setup, follow these steps:

1. Turn on or restart the computer, and then press **esc** while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
 - To select a menu or a menu item, use the **tab** key and the keyboard arrow keys and then press **enter**, or use a pointing device to click the item.
 - To scroll up and down, click the up arrow or the down arrow in the upper-right corner of the screen, or use the up arrow key or the down arrow key.
 - To close open dialog boxes and return to the main Computer Setup screen, press **esc**, and then follow the on-screen instructions.



NOTE: You can use either a pointing device (TouchPad, pointing stick, or USB mouse) or the keyboard to navigate and make selections in Computer Setup.

2. Press **f10** to enter Computer Setup.

To exit Computer Setup menus, choose one of the following methods:

- To exit Computer Setup menus without saving your changes:

Click the **Exit** icon in the lower-left corner of the screen, and then follow the on-screen instructions.

– or –

Use the **tab** key and the arrow keys to select **File > Ignore Changes and Exit**, and then press **enter**.

- To save your changes and exit Computer Setup menus:

Click the **Save** icon in the lower-right corner of the screen, and then follow the on-screen instructions.

– or –

Use the **tab** key and the arrow keys to select **File > Save Changes and Exit**, and then press **enter**.

Your changes go into effect when the computer restarts.

Restoring factory settings in Computer Setup

 **NOTE:** Restoring defaults will not change the hard drive mode.

To return all settings in Computer Setup to the values that were set at the factory, follow these steps:

1. Turn on or restart the computer, and then press **esc** while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
2. Press **f10** to enter Computer Setup.
3. Use a pointing device or the arrow keys to select **File > Restore Defaults**.
4. Follow the on-screen instructions.
5. To save your changes and exit, click the **Save** icon in the lower-right corner of the screen, and then follow the on-screen instructions.

– or –

Use the arrow keys to select **File > Save Changes and Exit**, and then press **enter**.

Your changes go into effect when the computer restarts.

 **NOTE:** Your password settings and security settings are not changed when you restore the factory settings.

Updating the BIOS

Updated versions of the BIOS may be available on the HP website.

Most BIOS updates on the HP website are packaged in compressed files called *SoftPaqs*.

Some download packages contain a file named *Readme.txt*, which contains information regarding installing and troubleshooting the file.

Determining the BIOS version

To determine whether available BIOS updates contain later BIOS versions than those currently installed on the computer, you need to know the version of the system BIOS currently installed.

BIOS version information (also known as *ROM date* and *System BIOS*) can be displayed by pressing **fn+esc** (if you are already in Windows) or by using Computer Setup.

1. Start Computer Setup.
2. Use a pointing device or the arrow keys to select **File > System Information**.
3. To exit Computer Setup without saving your changes, click the **Exit** icon in the lower-left corner of the screen, and then follow the on-screen instructions.

– or –

Use the **tab** key and the arrow keys to select **File > Ignore Changes and Exit**, and then press **enter**.

Downloading a BIOS update

 **CAUTION:** To reduce the risk of damage to the computer or an unsuccessful installation, download and install a BIOS update only when the computer is connected to reliable external power using the AC adapter. Do not download or install a BIOS update while the computer is running on battery power, docked in an optional docking device, or connected to an optional power source. During the download and installation, follow these instructions:

Do not disconnect power on the computer by unplugging the power cord from the AC outlet.

Do not shut down the computer or initiate Sleep.

Do not insert, remove, connect, or disconnect any device, cable, or cord.

1. From the Start screen, type `help` and then select **Help and Support**.
2. In the **Help and Support** search box, type `maintain`, and then follow the on-screen instructions to identify your computer and access the BIOS update you want to download.
3. At the download area, follow these steps:
 - a. Identify the BIOS update that is later than the BIOS version currently installed on your computer. Make a note of the date, name, or other identifier. You may need this information to locate the update later, after it has been downloaded to your hard drive.
 - b. Follow the on-screen instructions to download your selection to the hard drive.

Make a note of the path to the location on your hard drive where the BIOS update is downloaded. You will need to access this path when you are ready to install the update.

 **NOTE:** If you connect your computer to a network, consult the network administrator before installing any software updates, especially system BIOS updates.

BIOS installation procedures vary. Follow any instructions that are displayed on the screen after the download is complete. If no instructions are displayed, follow these steps:

1. From the Start screen, type `windows explorer`, and then click **Windows Explorer**.
2. Double-click your hard drive designation. The hard drive designation is typically Local Disk (C:).
3. Using the hard drive path you recorded earlier, open the folder on your hard drive that contains the update.
4. Double-click the file that has an `.exe` extension (for example, `filename.exe`).
The BIOS installation begins.
5. Complete the installation by following the on-screen instructions.

 **NOTE:** After a message on the screen reports a successful installation, you can delete the downloaded file from your hard drive.

Using Advanced System Diagnostics

Advanced System Diagnostics allows you to run diagnostic tests to determine if the computer hardware is functioning properly. The following diagnostic tests are available in Advanced System Diagnostics:

- **System Tune-Up**—This group of additional tests checks your computer to make sure that the main components are functioning correctly. System Tune-Up runs longer and more comprehensive tests on memory modules, hard drive SMART attributes, the hard drive surface, the battery (and battery calibration), video memory, and the WLAN module status.
- **Start-up test**—This test analyzes the main computer components that are required to start the computer.
- **Run-in test**—This test repeats the start-up test and checks for intermittent problems that the start-up test does not detect.
- **Hard disk test**—This test analyzes the physical condition of the hard drive, and then checks all data in every sector of the hard drive. If the test detects a damaged sector, it attempts to move the data to a good sector.
- **Memory test**—This test analyzes the physical condition of the memory modules. If it reports an error, replace the memory modules immediately.
- **Battery test**—This test analyzes the condition of the battery and calibrates the battery if necessary. If the battery fails the test, contact HP support to report the issue and purchase a replacement battery.
- **BIOS Management**—You can update or rollback the version of the BIOS on the system. Do not shut down or remove external power during the process. You will be given a confirmation screen before your BIOS is modified. Select **BIOS update**, **BIOS Rollback**, or **Back to main menu**.

You can view system information and error logs or select languages in the Advanced System Diagnostics window.

To start Advanced System Diagnostics:

1. Turn on or restart the computer. While the “Press the ESC key for Startup Menu” message is displayed in the lower-left corner of the screen, press **esc**. When the Startup Menu is displayed, press **f2**.
2. Click the diagnostic test you want to run, and then follow the on-screen instructions.



NOTE: If you need to stop a diagnostics test while it is running, press **esc**.

SUSE Linux – Computer Setup (BIOS) and Advanced System Diagnostics

Computer Setup, or Basic Input/Output System (BIOS), controls communication between all the input and output devices on the system (such as disk drives, display, keyboard, mouse, and printer). Computer Setup includes settings for the types of devices installed, the startup sequence of the computer, and the amount of system and extended memory.

 **NOTE:** Use extreme care when making changes in Computer Setup. Errors can prevent the computer from operating properly.

Starting Computer Setup

 **NOTE:** An external keyboard or mouse connected to a USB port can be used with Computer Setup only if USB legacy support is enabled.

To start Computer Setup, follow these steps:

1. Turn on or restart the computer, and then press **esc** while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
2. Press **f10** to enter Computer Setup.

Using Computer Setup

Navigating and selecting in Computer Setup

To navigate and select in Computer Setup, follow these steps:

1. Turn on or restart the computer, and then press **esc** while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
 - To select a menu or a menu item, use the **tab** key and the keyboard arrow keys and then press **enter**, or use a pointing device to click the item.
 - To scroll up and down, click the up arrow or the down arrow in the upper-right corner of the screen, or use the up arrow key or the down arrow key.
 - To close open dialog boxes and return to the main Computer Setup screen, press **esc**, and then follow the on-screen instructions.

 **NOTE:** You can use either a pointing device (TouchPad, pointing stick, or USB mouse) or the keyboard to navigate and make selections in Computer Setup.

2. Press **f10** to enter Computer Setup.

To exit Computer Setup menus, choose one of the following methods:

- To exit Computer Setup menus without saving your changes:

Click the **Exit** icon in the lower-left corner of the screen, and then follow the on-screen instructions.

– or –

Use the **tab** key and the arrow keys to select **File > Ignore Changes and Exit**, and then press **enter**.

- To save your changes and exit Computer Setup menus:

Click the **Save** icon in the lower-right corner of the screen, and then follow the on-screen instructions.

– or –

Use the **tab** key and the arrow keys to select **File > Save Changes and Exit**, and then press **enter**.

Your changes go into effect when the computer restarts.

Restoring factory settings in Computer Setup

 **NOTE:** Restoring defaults will not change the hard drive mode.

To return all settings in Computer Setup to the values that were set at the factory, follow these steps:

1. Turn on or restart the computer, and then press **esc** while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
2. Press **f10** to enter Computer Setup.
3. Use a pointing device or the arrow keys to select **File > Restore Defaults**.
4. Follow the on-screen instructions.
5. To save your changes and exit, click the **Save** icon in the lower-right corner of the screen, and then follow the on-screen instructions.

– or –

Use the arrow keys to select **File > Save Changes and Exit**, and then press **enter**.

Your changes go into effect when the computer restarts.

 **NOTE:** Your password settings and security settings are not changed when you restore the factory settings.

Updating the BIOS

Updated versions of the BIOS may be available on the HP website.

Most BIOS updates on the HP website are packaged in compressed files called *SoftPaqs*.

Some download packages contain a file named *Readme.txt*, which contains information regarding installing and troubleshooting the file.

Determining the BIOS version

To determine whether available BIOS updates contain later BIOS versions than those currently installed on the computer, you need to know the version of the system BIOS currently installed.

BIOS version information (also known as *ROM date* and *System BIOS*) can be displayed by pressing **fn+esc** (if you are already in Windows) or by using Computer Setup.

1. Start Computer Setup.
2. Use a pointing device or the arrow keys to select **File > System Information**.
3. To exit Computer Setup without saving your changes, click the **Exit** icon in the lower-left corner of the screen, and then follow the on-screen instructions.

– or –

Use the **tab** key and the arrow keys to select **File > Ignore Changes and Exit**, and then press **enter**.

Downloading a BIOS update

 **CAUTION:** To reduce the risk of damage to the computer or an unsuccessful installation, download and install a BIOS update only when the computer is connected to reliable external power using the AC adapter. Do not download or install a BIOS update while the computer is running on battery power, docked in an optional docking device, or connected to an optional power source. During the download and installation, follow these instructions:

Do not disconnect power on the computer by unplugging the power cord from the AC outlet.

Do not shut down the computer or initiate Sleep.

Do not insert, remove, connect, or disconnect any device, cable, or cord.

1. From the Start screen, type `help` and then select **Help and Support**.
2. In the **Help and Support** search box, type `maintain`, and then follow the on-screen instructions to identify your computer and access the BIOS update you want to download.
3. At the download area, follow these steps:
 - a. Identify the BIOS update that is later than the BIOS version currently installed on your computer. Make a note of the date, name, or other identifier. You may need this information to locate the update later, after it has been downloaded to your hard drive.
 - b. Follow the on-screen instructions to download your selection to the hard drive.

Make a note of the path to the location on your hard drive where the BIOS update is downloaded. You will need to access this path when you are ready to install the update.

 **NOTE:** If you connect your computer to a network, consult the network administrator before installing any software updates, especially system BIOS updates.

BIOS installation procedures vary. Follow any instructions that are displayed on the screen after the download is complete. If no instructions are displayed, follow these steps:

1. From the Start screen, type `windows explorer`, and then click **Windows Explorer**.
2. Double-click your hard drive designation. The hard drive designation is typically Local Disk (C:).
3. Using the hard drive path you recorded earlier, open the folder on your hard drive that contains the update.
4. Double-click the file that has an `.exe` extension (for example, `filename.exe`).
The BIOS installation begins.
5. Complete the installation by following the on-screen instructions.

 **NOTE:** After a message on the screen reports a successful installation, you can delete the downloaded file from your hard drive.

Using Advanced System Diagnostics

Advanced System Diagnostics allows you to run diagnostic tests to determine if the computer hardware is functioning properly. The following diagnostic tests are available in Advanced System Diagnostics:

- **Start-up test**—This test analyzes the main computer components that are required to start the computer.
- **Run-in test**—This test repeats the start-up test and checks for intermittent problems that the start-up test does not detect.
- **Hard disk test**—This test analyzes the physical condition of the hard drive, and then checks all data in every sector of the hard drive. If the test detects a damaged sector, it attempts to move the data to a good sector.
- **Memory test**—This test analyzes the physical condition of the memory modules. If it reports an error, replace the memory modules immediately.
- **Battery test**—This test analyzes the condition of the battery and calibrates the battery if necessary. If the battery fails the test, contact support to report the issue and purchase a replacement battery.
- **System Tune-Up**—This group of additional tests checks your computer to make sure that the main components are functioning correctly. System Tune-Up runs longer and more comprehensive tests on memory modules, hard drive SMART attributes, the hard drive surface, the battery (and battery calibration), video memory, and the WLAN module status.

You can view system information and error logs in the Advanced System Diagnostics window.

To start Advanced System Diagnostics:

1. Turn on or restart the computer. While the “Press the ESC key for Startup Menu” message is displayed in the lower-left corner of the screen, press **esc**. When the Startup Menu is displayed, press **f2**.
2. Click the diagnostic test you want to run, and then follow the on-screen instructions.



NOTE: If you need to stop a diagnostics test while it is running, press **esc**.

6 Specifications

Computer specifications

	Metric	U.S.
Dimensions		
Length	23.5 cm	9.3 in
Width	33.9 cm	13.4 in
Height (front to rear)	2.8 to 3.5 cm	1.1 to 1.4 in
Weight (equipped with optical drive, 1 SODIMM, hard drive, WLAN module, 6 cell battery)	2.1 kg	4.6 lbs
Input power		
Operating voltage	19.0 V dc @ 4.74 A – 90 W or 18.5 V dc @ 3.5 A - 65 W	
Operating current	4.74 A or 3.5 A	
Temperature		
Operating	5°C to 35°C	41°F to 95°F
Nonoperating	-20°C to 60°C	-4°F to 140°F
Relative humidity (noncondensing)		
Operating	10% to 90%	
Nonoperating	5% to 95%	
Maximum altitude (unpressurized)		
Operating	-15 m to 3,048 m	-50 ft to 10,000 ft
Nonoperating	-15 m to 12,192 m	-50 ft to 40,000 ft
Shock		
Operating	125 g, 2 ms, half-sine	
Nonoperating	200 g, 2 ms, half-sine	
Random vibration		
Operating	0.75 g zero-to-peak, 10 Hz to 500 Hz, 0.25 oct/min sweep rate	
Nonoperating	1.50 g zero-to-peak, 10 Hz to 500 Hz, 0.5 oct/min sweep rate	
NOTE: Applicable product safety standards specify thermal limits for plastic surfaces. The computer operates well within this range of temperatures.		

35.6-cm (14.0-in), HD display specifications

	Metric	U.S.
Active diagonal size	35.6-cm	14.0-in
Resolution	1366x768 (HD)	
Active area	309.399x173.952	
PPI	112	
Surface treatment	Anti-glare or BrightView	
Contrast ratio	300:1 (typical) – Anti-glare 500:1 – BrightView	
Response time	8 ms	
Brightness	200 nits (typical)	
Viewing angle	SVA	
Backlight	LED	
Luminance uniformity @ 13 points	1.4 (typ), 1.6 (max)	
Lifetime (1/2 luminance)	12,000 hours	
Color coordinate (white)	(0.313, 0.329)	
Color tolerance (W, R, G, B)	+/- 0.03	
Color gamut	45% typ	

Hard drive specifications

	750-GB*	640-GB*	320-GB*
Dimensions			
Height	9.5 mm	9.5 mm	9.5 mm
Width	70 mm	70 mm	70 mm
Weight	115 g	101 g	101 g
Interface type	SATA	SATA	SATA
Transfer rate	100 MB/sec	100 MB/sec	100 MB/sec
Security	ATA security	ATA security	ATA security
Seek times (typical read, including setting)			
Single track	1.5 ms	2 ms	3 ms
Average	11 ms	12 ms	13 ms
Maximum	14 ms	22 ms	24 ms
Logical blocks	1,465,149,168	1,250,263,728	625,141,400
Disc rotational speed	7200 rpm or 5400 rpm		

	750-GB*	640-GB*	320-GB*
Operating temperature	5°C to 55°C (41°F to 131°F)		
*1 GB = 1 billion bytes when referring to hard drive storage capacity. Actual accessible capacity is less. Actual drive specifications may differ slightly.			
NOTE: Certain restrictions and exclusions apply. Contact technical support for details.			

Blu-ray BD-R/RE DVD±RW SuperMulti DL Drive

Applicable disc	Read:	Write:	
	CD-DA, CD+(E)G, CD-MIDI, CD-TEXT, CD-ROM, CD-ROM XA, MIXED MODE CD, CD-I, CD-I Bridge (Photo-CD, Video CD), Multisession CD (Photo-CD, CD-EXTRA, Portfolio, CD-R, CD-RW), CD-R, CD-RW, DVD-ROM (DVD-5, DVD-9, DVD-10, DVD-18), DVD-R, DVD-RW, DVD+R, DVD+RW, DVD-RAM, BD-ROM, BD-R, BD-RE	CD-R, CD-RW, DVD+R, DVD+R(9), DVD+RW, DVD-R, DVD-R(9), DVD-RW, DVD-RAM, BD-R, BD-RE	
Access time	CD	DVD	BD-ROM
Random	<180 ms	<180 ms	<230 ms
Maximum Media Capacity (read)	50 GB		
Maximum Media Capacity (write)	8.5 GB		
Data transfer rate			
24X CD-ROM	3,600 KB/sec		
8X DVD	10,800 KB/sec		
2X BD-ROM	9,000 KB/sec		
16X CD-R	3,600 KB/sec		
16X CD-RW	2,400 KB/sec		
8X DVD+R	10,800 KB/sec		
6X DVD+RW	8,100 KB/sec		
8X DVD-R	10,800 KB/sec		
6X DVD-RW	8,100 KB/sec		
4X DVD+R Dual Layer	5,400 KB/sec		
4X DVD-R Dual Layer	5,400 KB/sec		
5X DVD-RAM	6,750 KB/sec		
2X BD-R	9,000 KB/sec		
2X BD-RE	9,000 KB/sec		

DVD-ROM Drive specifications

Applicable disc	DVD-ROM (DVD-5, DVD-9, DVD-10, DVD-18, CD-ROM (Mode 1 and 2), CD Digital Audio, CD-XA ready (Mode 2, Form 1 and Form 2), CD-I (Mode 2, Form 1 and Form 2), CD-R, CD-RW, Photo CD (single and multisession), CD-Bridge	
Center hole diameter	1.5 cm (0.59 in)	
Disc diameter		
Standard disc	12 cm (4.72 in)	
Mini disc	8 cm (3.15 in)	
Disc thickness	1.2 mm (0.047 in)	
Track pitch	0.74 μ m	
Access time	CD	DVD
Random	< 100 ms	< 125 ms
Full stroke	< 175 ms	< 225 ms
Audio output level	Line-out, 0.7 Vrms	
Cache buffer	512 KB	
Data transfer rate		
CD-R (24X)	3600 KB/s (150 KB/s at 1X CD rate)	
CD-RW (10X)	1500 KB/s (150 KB/s at 1X CD rate)	
CD-ROM (24X)	3600 KB/s (150 KB/s at 1X CD rate)	
DVD (8X)	10,800 KB/s (1,352 KB/s at 1X DVD rate)	
Multiword DMA mode 2	16.6 MB/s	
Startup time	< 10 seconds	
Stop time	< 3 seconds	

Specification information in Device Manager

Device Manager allows you to view and control the hardware attached to the computer, as well as provides hardware specification information.

You can also add hardware or modify device configurations using Device Manager.



NOTE: Windows 7 includes the User Account Control feature to improve the security of your computer. You may be prompted for your permission or password for tasks such as installing software, running utilities, or changing Windows settings. Refer to Windows Help and Support for more information.

After you open Device Manager, drill-down to a device and double-click it to access its properties.

To access Device Manager in Windows 8:

1. From the Start screen type **control**, and then select **Control Panel**.
2. A list displays all the devices installed in your computer.

To access Device Manager in Windows 7:

1. Select **Start > Computer > System properties**.
2. In the left pane, click **Device Manager**.

7 Backup and recovery

Windows 7 - Backup and recovery

To protect your information, use Windows Backup and Recovery to back up individual files and folders, back up your entire hard drive (select models only), create system repair discs (select models only) with the installed optical drive (select models only) or an optional external optical drive, or create system restore points. In case of system failure, you can use the backup files to restore the contents of your computer.

Windows Backup and Recovery provides the following options:

- Creating a system repair disc (select models only) by using the installed optical drive (select models only) or an optional external optical drive
- Backing up your information
- Creating a system image (select models only)
- Scheduling automatic backups (select models only)
- Creating system restore points
- Recovering individual files
- Restoring the computer to a previous state
- Recovering information using recovery tools

 **NOTE:** For detailed instructions, perform a search for these topics in Help and Support.

In case of system instability, HP recommends that you print the recovery procedures and save them for later use.

 **NOTE:** Windows includes the User Account Control feature to improve the security of your computer. You may be prompted for your permission or password for tasks such as installing software, running utilities, or changing Windows settings. [See Help and Support for more information.](#)

Creating recovery media with HP Recovery Disc Creator

HP Recovery Disc Creator is a software program that offers an alternative way to create recovery media. After you successfully set up the computer, you can create recovery media using HP Recovery Disc Creator. This recovery media allows you to reinstall your original operating system as well as select drivers and applications if the hard drive becomes corrupted.

HP Recovery Disc Creator can create two kinds of recovery DVDs as follows:

- Windows Disc—Installs the operating system without additional drivers or applications.
- Driver Disc—Installs specific drivers and applications only, in the same way that the HP Software Setup utility installs drivers and applications.

Creating recovery media

 **NOTE:** The Windows Disc can be created only once. Thereafter, the option to create that media will not be available.

1. Select **Start > All Programs > Productivity and Tools > HP Recovery Disc Creator**.
2. Select **Driver Disc** or **Windows Disc**.
3. From the drop-down menu, select the drive for burning the recovery media.
4. Click the **Create** button to start the burning process.

Backing up your information

Recovery after a system failure is as good as your most recent backup. Immediately after setting up the computer, you should create system repair discs (select models only) using the installed optical drive (select models only) or an optional external optical drive and back up your system. As you add new software and data files, you should continue to back up your system on a regular basis to maintain a reasonably current backup. The system repair discs (select models only) are used to start up (boot) the computer and repair the operating system in case of system instability or failure. Your initial and subsequent backups allow you to restore your data and settings if a failure occurs.

You can back up your information to an optional external hard drive, a network drive, or discs.

Note the following when backing up:

- Store personal files in the Documents library, and back it up regularly.
- Back up templates that are stored in their associated programs.
- Save customized settings that appear in a window, toolbar, or menu bar by taking a screen shot of your settings. The screen shot can be a time-saver if you have to reset your preferences.
- When backing up to discs, use any of the following types of discs (purchased separately): CD-R, CD-RW, DVD+R, DVD+R DL, DVD-R, DVD-R DL, or DVD±RW. The discs you use will depend on the type of optical drive you are using.

 **NOTE:** DVDs and DVDs with double-layer (DL) support store more information than CDs, so using them for backup reduces the number of recovery discs required.

- When backing up to discs, number each disc before inserting it into the external drive.

To create a backup using Backup and Restore:

 **NOTE:** Be sure that the computer is connected to AC power before you start the backup process.

 **NOTE:** The backup process may take over an hour, depending on file size and the speed of the computer.

1. Select **Start > All Programs > Maintenance > Backup and Restore**.
2. Follow the on-screen instructions to set up your backup, create a system image (select models only), or create a system repair disc (select models only).

Performing a system recovery

In case of system failure or instability, the computer provides the following tools to recover your files:

- Windows recovery tools: You can use Windows Backup and Restore to recover information you have previously backed up. You can also use Windows Startup Repair to fix problems that might prevent Windows from starting correctly.
- **f11** recovery tools: You can use the **f11** recovery tools to recover your original hard drive image. The image includes the Windows operating system and software programs installed at the factory.

 **NOTE:** If you are unable to boot (start up) your computer and you cannot use the system repair discs you previously created (select models only), you must purchase a Windows 7 operating system DVD to reboot the computer and repair the operating system. For additional information, see the Using a Windows 7 operating system DVD (purchased separately) section.

Using the Windows recovery tools

To recover information you previously backed up:

1. Select **Start > All Programs > Maintenance > Backup and Restore**.
2. Follow the on-screen instructions to recover your system settings, your computer (select models only), or your files.

To recover your information using Startup Repair, follow these steps:

 **CAUTION:** Some Startup Repair options completely erase hard drive contents and reformat the hard drive. All files you have created and any software installed on the computer are permanently removed. When reformatting is complete, the recovery process restores the operating system, as well as the drivers, software, and utilities from the backup used for recovery.

1. If possible, back up all personal files.
2. If possible, check for the presence of the Windows partition.
To check for the Windows partition, select **Start > Computer**.
3. If the Windows partition is listed, restart the computer, and then press **f8** before the Windows operating system loads.
4. Select **Startup Repair**.
5. Follow the on-screen instructions.

 **NOTE:** For additional information on recovering information using the Windows tools, perform a search for these topics in Help and Support.

Using f11 recovery tools

 **CAUTION:** Using **f11** recovery tools completely erases hard drive contents and reformats the hard drive. All files you have created and any software installed on the computer are permanently removed. The **f11** recovery tool reinstalls the operating system and HP programs and drivers that were installed at the factory. Software not installed at the factory must be reinstalled.

To recover the original hard drive image using **f11**:

1. If possible, back up all personal files.
2. If possible, check for the presence of the HP Recovery partition: click **Start**, right-click **Computer**, click **Manage**, and then click **Disk Management**.

 **NOTE:** If the HP Recovery partition has been deleted, the **f11** restore option will not function. You must recover your operating system and programs using the Windows 7 operating system DVD and the Driver Recovery disc (both purchased separately) if the Windows partition and the HP Recovery partition are not listed. For additional information, see the Using a Windows 7 operating system DVD (purchased separately) section.

3. If the HP Recovery partition is listed, restart the computer, and then press **esc** while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
4. Press **f11** while the “Press <F11>” for recovery” message is displayed on the screen.
5. Follow the on-screen instructions.

Using a Windows 7 operating system DVD (purchased separately)

To order a Windows 7 operating system DVD, go to the HP website. For U.S. support, go to <http://www.hp.com/go/contactHP>. For worldwide support, go to http://welcome.hp.com/country/us/en/wwcontact_us.html. You can also order the DVD by calling support. For contact information, see the *Worldwide Telephone Numbers* booklet included with the computer.

 **CAUTION:** Using a Windows 7 operating system DVD completely erases hard drive contents and reformats the hard drive. All files you have created and any software installed on the computer are permanently removed. When reformatting is complete, the recovery process helps you restore the operating system, as well as drivers, software, and utilities.

To initiate recovery using a Windows 7 operating system DVD:

 **NOTE:** This process takes several minutes.

1. If possible, back up all personal files.
2. Restart the computer, and then insert the Windows 7 operating system DVD into the optical drive before the Windows operating system loads.
3. When prompted, press any keyboard key.
4. Follow the on-screen instructions.
5. Click **Next**.
6. Select **Repair your computer**.
7. Follow the on-screen instructions.

After the repair is completed:

1. Eject the Windows 7 operating system DVD, and then insert the Driver Recovery disc.
2. Install the Hardware Enabling Drivers first, and then install Recommended Applications.

Windows 8 - Backup and recovery

To protect your information, use Windows backup and restore utilities to back up individual files and folders, back up your entire hard drive, create system repair media (select models only) by using the installed optical drive (select models only) or an optional external optical drive, or create system restore points. In case of system failure, you can use the backup files to restore the contents of your computer.

From the Start screen, type `restore`, click **Settings**, and then select from the list of displayed options.

 **NOTE:** For detailed instructions on various backup and restore options, perform a search for these topics in Help and Support. From the Start screen, type `h`, and then select **Help and Support**.

In case of system instability, HP recommends that you print the recovery procedures and save them for later use.

 **NOTE:** Windows includes the User Account Control feature to improve the security of your computer. You may be prompted for your permission or password for tasks such as installing software, running utilities, or changing Windows settings. Refer to Help and Support for more information. From the Start screen, type `h`, and then select **Help and Support**.

Backing up your information

Recovery after a system failure is as good as your most recent backup. You should create system repair media and your initial backup immediately after initial system setup. As you add new software and data files, you should continue to back up your system on a regular basis to maintain a reasonably current backup. The system repair media (select models only) are used to start up (boot) the computer and repair the operating system in case of system instability or failure. Your initial and subsequent backups allow you to restore your data and settings if a failure occurs.

On Start screen, type `backup`, click **Settings**, and then select **Save backup copies of your files with File History**.

You can back up your information to an optional external hard drive or a network drive.

Note the following when backing up:

- Store personal files in the Documents library, and back it up regularly.
- Back up templates that are stored in their associated programs.
- Save customized settings that appear in a window, toolbar, or menu bar by taking a screen shot of your settings. The screen shot can be a time-saver if you have to reset your preferences.

To create a backup using Backup and Restore:

 **NOTE:** Be sure that the computer is connected to AC power before you start the backup process.

 **NOTE:** The backup process may take over an hour, depending on file size and the speed of the computer.

1. From the Start screen, type `backup`, click **Settings**, and then select from the list of displayed options.
2. Follow the on-screen instructions to set up your backup, create a system image (select models only), or create system repair media (select models only).

Performing a system recovery

In case of system failure or instability, the computer provides the following tools to recover your files:

- Windows recovery tools: You can use Windows Backup and Restore to recover information you have previously backed up. You can also use Windows Automatic Repair to fix problems that might prevent Windows from starting correctly.
- f11 recovery tools: You can use the f11 recovery tools to recover your original hard drive image. The image includes the Windows operating system and software programs installed at the factory.

 **NOTE:** If you are unable to boot (start up) your computer and you cannot use the system repair media you previously created (select models only), you must purchase Windows 8 operating system media to reboot the computer and repair the operating system. For additional information, see [Using Windows 8 operating system media \(purchased separately\) on page 110](#).

Using the Windows recovery tools

To recover information you previously backed up:

- ▲ From the Start screen, type **h**, and then select **Help and Support**.

To recover your information using Automatic Repair, follow these steps:

 **CAUTION:** Some Automatic Repair options will completely erase and reformat the hard drive. All files you have created and any software installed on the computer are permanently removed. When reformatting is complete, the recovery process restores the operating system, as well as the drivers, software, and utilities from the backup used for recovery.

1. If possible, back up all personal files.
2. If possible, check for the presence of the HP Recovery partition and the Windows partition.

From the Start screen, type **e**, and then click **File Explorer**.

– or –

From the Start screen, type **c**, and then select **Computer**.

 **NOTE:** If the Windows partition and the HP Recovery partition are not listed, you must recover your operating system and programs using the Windows 8 operating system DVD and the *Driver Recovery* media (both purchased separately). For additional information, see [Using Windows 8 operating system media \(purchased separately\) on page 110](#).

3. If the Windows partition and the HP Recovery partition are listed, restart the computer. After Windows has loaded, press and hold the **shift** key while clicking **Restart**.
4. Select **Troubleshoot**, select **Advanced Options**, and then select **Automatic Repair**.
5. Follow the on-screen instructions.

 **NOTE:** For additional information on recovering information using the Windows tools, perform a search for these topics in Help and Support. From the Start screen, type **h**, and then select **Help and Support**.

Using f11 recovery tools

 **CAUTION:** Using f11 completely erases hard drive contents and reformats the hard drive. All files that you have created and any software that you have installed on the computer are permanently removed. The f11 recovery tool reinstalls the operating system and HP programs and drivers that were installed at the factory. Software not installed at the factory must be reinstalled.

To recover the original hard drive image using **f11**:

1. If possible, back up all personal files.
2. If possible, check for the presence of the HP Recovery partition: From the Start screen, type **c**, and then select **Computer**.

 **NOTE:** If the HP Recovery partition is not listed, you must recover your operating system and programs using the Windows 8 operating system media and the *Driver Recovery* media (both purchased separately). For additional information, see [Using Windows 8 operating system media \(purchased separately\) on page 110](#).

3. If the HP Recovery partition is listed, restart the computer, and then press **esc** while the “Press the ESC key for Startup Menu” message is displayed at the bottom of the screen.
4. Press **f11** while the “Press <F11> for recovery” message is displayed on the screen.
5. Follow the on-screen instructions.

Using Windows 8 operating system media (purchased separately)

To order a Windows 8 operating system DVD, go to <http://www.hp.com/support>, select your country or region, and follow the on-screen instructions. You can also order the DVD by calling support. For contact information, see the *Worldwide Telephone Numbers* booklet included with the computer.

 **CAUTION:** Using a Windows 8 operating system media completely erases hard drive contents and reformats the hard drive. All files that you have created and any software that you have installed on the computer are permanently removed. When reformatting is complete, the recovery process helps you restore the operating system, as well as drivers, software, and utilities.

To initiate recovery using a Windows 8 operating system DVD:

 **NOTE:** This process takes several minutes.

1. If possible, back up all personal files.
2. Restart the computer, and then insert the Windows 8 operating system DVD into the optical drive before the Windows operating system loads.
3. When prompted, press any keyboard key.
4. Follow the on-screen instructions.

After the repair is completed:

1. Eject the Windows 8 operating system media and then insert the *Driver Recovery* media.
2. Install the Hardware Enabling Drivers first, and then install Recommended Applications.

Using Windows Refresh for quick and easy recovery

When your computer is not working properly and you need to regain system stability, the Windows Refresh option allows you to start fresh and keep what is important to you.

 **IMPORTANT:** Refresh removes any traditional applications that were not originally installed on the system at the factory.

 **NOTE:** During Refresh, a list of removed traditional applications will be saved so that you have a quick way to see what you might need to reinstall. See Help and Support for instructions on reinstalling traditional applications. From the Start screen, type **h**, and then select **Help and Support**.

 **NOTE:** You may be prompted for your permission or password when using Refresh. See Windows Help and Support for more information. From the Start screen, type `h`, and then select **Help and Support**.

To start Refresh:

1. On the Start screen, point to the far-right upper or lower corner of the screen to display the charms.
2. Click **Settings**.
3. Click **Change PC settings** in the bottom-right corner of the screen, and then select **General** from the PC settings screen.
4. Under **Refresh your PC without affecting your files**, select **Get started**, and follow the on-screen instructions.

Remove everything and reinstall Windows

Sometimes you want to perform detailed reformatting of your computer, or you want to remove personal information before you give away or recycle your computer. The process described in this section provides a speedy, simple way to return the computer to its original state. This option removes all personal data, apps, and settings from your computer, and reinstalls Windows.

 **IMPORTANT:** This option does not provide backups of your information. Before using this option, back up any personal information you wish to retain.

You can initiate this option by using the `f11` key or from the Start screen.

To use the `f11` key:

1. Press `f11` while the computer boots.
– or –
Press and hold `f11` as you press the power button.
2. Select **Troubleshoot** from the boot options menu.
3. Select **Reset your PC**, and follow the on-screen instructions.

To use the Start screen:

1. On the Start screen, point to the far-right upper or lower corner of the screen to display the charms.
2. Click **Settings**.
3. Click **Change PC settings** in the bottom-right corner of the screen, and then select **General** from the PC settings screen.
4. Under **Remove everything and reinstall Windows**, select **Get started**, and follow the on-screen instructions.

Using HP Software Setup

HP Software Setup can be used to reinstall drivers or select software that has been corrupted or deleted from the system.

1. From the Start screen, type `HP Software Setup`, and select **Apps**.
2. Open HP Software Setup.
3. Follow the on-screen directions to reinstall drivers or select software.

SUSE Linux - Backup and recovery

Recovery after a system failure is as good as your most recent backup. As you add new software and data files, you should continue to back up your system on a regular basis to maintain a reasonably current backup.

Your computer includes tools provided by HP to help you safeguard your information and retrieve it if ever needed.

Creating backups

1. Create restore media immediately after you set up the computer. For more information, see [Performing a system recovery on page 113](#).
2. As you add files, routinely create a backup of your system and personal information.

Backing up your information

You should back up your computer files on a regular schedule to maintain a current backup. You can manually back up your information to an optional external drive, a network drive, or discs. Back up your system at the following times:

- At regularly scheduled times
- Before the computer is repaired or restored
- Before you add or modify hardware or software

To back up your home directory files using **Backup Manager Settings**:

1. Select **Computer > More Applications > Tools > Backup Manager Settings**, and click **Backup my home directory**.
2. Click **Storage Destination Location**, and then select a location to back up your information.
3. Click **Schedule**, and then select a time schedule to perform backups at a regularly scheduled time.

To immediately back up your information, click the **Backup Now** check box.



NOTE: Before you back up your information, be sure you have designated a location to save the backup files.

4. Click **Save and Backup** to start the backup and to save the backup settings.

To restore backup files:

1. Select **Computer > More Applications > Tools > Backup Manager Restore**.
2. Click **Backup Source**, and then select the location of the backup files.
3. Click **Restore Destination**, and then select the destination to restore the files.
4. To restore all files from the selected location, click **Restore all files**. To restore select files only, click **Restore selected files**, click **Select Files** and then select the files to be restored.
5. Under **Restore Point**, click the time and date of the backup.



NOTE: If multiple backups have been performed, click **Use the latest version** to restore the latest version.

6. Click **Restore** to start restoring the files, or click **Cancel** to cancel the operation.

Performing a system recovery

Recovery allows you to repair or restore the computer to its original factory state. You can create an HP Factory Image Restore DVD, using an installed or an external DVD±RW optical drive.

 **CAUTION:** Using Recovery completely erases hard drive contents and reformats the hard drive. All files you have created and any software installed on the computer are permanently removed. The recovery tool reinstalls the original operating system and HP programs and drivers that were installed at the factory. Software, drivers, and updates not installed by HP must be manually reinstalled. Personal files must be restored from a backup.

To restore the computer using the HP Factory Image Restore DVD, you must first create the recovery disc. To create the recovery disc:

 **NOTE:** HP recommends that you create the HP Factory Image Restore DVD in the event of a system failure.

1. Select **Computer > More Applications**.
2. In the left pane, click **Tools**, and then click **Create HP Factory Image Restore DVD** in the right pane.
3. Follow the on-screen instructions to create an image file to burn a recovery disc.

To restore the computer from the recovery disc, follow these steps:

1. If possible, back up all personal files.
2. Insert the HP Factory Image Restore DVD into the optical drive and restart the computer.
3. As the computer is restarting, press **f9** to open the Computer Setup boot option menu.
4. Press the down arrow to select **Restore SUSE Linux HP-BNB preload image** from the **Linux boot** menu, and then press **enter**.
5. Using the arrow keys, select **Yes** when prompted: **Do you want to start the System-Restore?**
6. Follow the on-screen instructions.

USB Recovery option (select models only)

The USB Recovery Disk On Key (flash drive) option allows you to create a backup image of the SUSE Linux operating system installed on select HP Business Notebooks. This Disk On Key may be used to restore the system to the original factory state when the F11 recovery option is not available. This process should be done on first obtaining the computer.

 **CAUTION:** The USB recovery option does not preserve data present on the computer's hard drive or on the Disk On Key used for the recovery process. Back up any data on the Disk on Key or the notebook that will be recovered before starting.

 **NOTE:** HP recommends that you create the USB Recovery Disk in the event of a system failure. The Disk On Key used for this process should be 4 GB or larger.

Creating a USB Recovery Disk On Key

1. Connect the USB Disk On Key to a USB port on the computer.
2. Select **Computer > More applications > Tools > Create Recovery USB**.
3. Enter the root password when prompted.
4. Select **USB Disk On Key** from the list.

5. Click **OK**.
6. A question dialog will remind you that the data on the USB key will be destroyed. To continue, click **OK**. Otherwise, click **Cancel** and back up the contents of the Disk On Key on another computer.
7. The backup process will display a status dialog box while the backup is in progress.



NOTE: A file browser window with the Disk On Key Contents displayed will pop up when the key is mounted. You may close the file browser window if desired. Once the USB Recovery Key has been created, the status dialog will close. The USB Recovery Key is ready for use.

Recovering from a USB Recovery Disk On Key



CAUTION: Before starting the Recovery process, make sure any data on the system to be recovered has been backed up. The recovery process destroys all data on the system to be recovered.

1. Turn off the computer.
2. Connect the USB Disk On Key to a USB port on the computer.
3. Turn on the computer while holding down the **f9** key.
4. Once the system has booted, the **Boot Options** menu should appear.
5. Using the arrow keys, select **USB Disk On Key** and press **enter**.



NOTE: The description may vary from one USB key to another. Any entry other than Optical Disk Drive, Notebook Hard Drive or Notebook Ethernet should be the USB Recovery Disk On Key.

6. Once the USB Recovery Disk On Key has been selected, press **enter**. The USB Recovery Disk On Key will boot.
7. Once the USB Recovery Disk On Key has booted, a dialog box will prompt, “Do you want to start the System-Restore?” If data on the computer has not been backed up, use the tab key and select **No**. The system will reboot. Back up the system data and repeat the previous steps. If no data should be saved from the computer, use the **tab** key to select **Yes**. Press **enter** to begin the recovery process.
8. After the files are copied to the system, follow the on-screen instructions.

Remove everything and reinstall SUSE Linux

Sometimes you want to perform detailed reformatting of your computer, or you want to remove personal information before you give away or recycle your computer. The process described in this section provides a speedy, simple way to return the computer to its original state. This option removes all personal data, applications, and settings from your computer, and reinstalls the Linux operating system.



IMPORTANT: This option does not provide backups of your information. Before using this option, back up any personal information you wish to retain.

You can initiate this option by using the **f11** key.

To use the **f11** key:

Press **f11** while the computer boots.

– or –

Press and hold **f11** as you press the power button.

The following options are available:

- **Cancel/Reboot**—Reboots the system. No recovery or restore activity is performed.
- **Recover/Repair System**—This option repairs a system that is not working properly and preserves user data.
- **Restore Factory System**—This option restores the system back to the original factory state. User data is not preserved.

Select an option and follow the on-screen instructions.

8 Power cord set requirements

The wide range input feature of the computer permits it to operate from any line voltage from 100 to 120 volts AC, or from 220 to 240 volts AC.

The 3-conductor power cord set included with the computer meets the requirements for use in the country or region where the equipment is purchased.

Power cord sets for use in other countries and regions must meet the requirements of the country or region where the computer is used.

Requirements for all countries and regions

The requirements listed below are applicable to all countries and regions:

- The length of the power cord set must be at least 1.0 m (3.3 ft) and no more than 2.0 m (6.5 ft).
- All power cord sets must be approved by an acceptable accredited agency responsible for evaluation in the country or region where the power cord set will be used.
- The power cord sets must have a minimum current capacity of 10 amps and a nominal voltage rating of 125 or 250 V AC, as required by the power system of each country or region.
- The appliance coupler must meet the mechanical configuration of an EN 60 320/IEC 320 Standard Sheet C13 connector for mating with the appliance inlet on the back of the computer.

Requirements for specific countries and regions

Country/region	Accredited agency	Applicable note number
Australia	EANSW	1
Austria	OVE	1
Belgium	CEBC	1
Canada	CSA	2
Denmark	DEMKO	1
Finland	FIMKO	1
France	UTE	1
Germany	VDE	1
Italy	IMQ	1
Japan	METI	3
The Netherlands	KEMA	1
Norway	NEMKO	1
The People's Republic of China	CCC	5
South Korea	EK	4

Country/region	Accredited agency	Applicable note number
Sweden	SEMKO	1
Switzerland	SEV	1
Taiwan	BSMI	4
The United Kingdom	BSI	1
The United States	UL	2

1. The flexible cord must be Type HO5VV-F, 3-conductor, 1.0-mm² conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the certification mark of the agency responsible for evaluation in the country or region where it will be used.
2. The flexible cord must be Type SPT-3 or equivalent, No. 18 AWG, 3-conductor. The wall plug must be a two-pole grounding type with a NEMA 5-15P (15 A, 125 V) or NEMA 6-15P (15 A, 250 V) configuration.
3. The appliance coupler, flexible cord, and wall plug must bear a "T" mark and registration number in accordance with the Japanese Dentori Law. The flexible cord must be Type VCT or VCTF, 3-conductor, 1.00-mm² conductor size. The wall plug must be a two-pole grounding type with a Japanese Industrial Standard C8303 (7 A, 125 V) configuration.
4. The flexible cord must be Type RVV, 3-conductor, 0.75-mm² conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the certification mark of the agency responsible for evaluation in the country or region where it will be used.
5. The flexible cord must be Type VCTF, 3-conductor, 0.75-mm² conductor size. Power cord set fittings (appliance coupler and wall plug) must bear the certification mark of the agency responsible for evaluation in the country or region where it will be used.

9 Recycling

Battery

When a non-rechargeable or rechargeable battery has reached the end of its useful life, do not dispose of the battery in general household waste. Follow the local laws and regulations in your area for battery disposal.

HP encourages customers to recycle used electronic hardware, HP original print cartridges, and rechargeable batteries. For more information about recycling programs, see the HP Web site at <http://www.hp.com/recycle>.

Display

! WARNING! The backlight contains mercury. Exercise caution when removing and handling the backlight to avoid damaging this component and causing exposure to the mercury.

! CAUTION: The procedures in this chapter can result in damage to display components. The only components intended for recycling purposes are the LCD panel and the backlight. When you remove these components, handle them carefully.

NOTE: Materials Disposal. This HP product contains mercury in the backlight in the display assembly that might require special handling at end-of-life. Disposal of mercury may be regulated because of environmental considerations. For disposal or recycling information, contact your local authorities, or see the Electronic Industries Alliance (EIA) Web site at <http://www.eiae.org>.


This section provides disassembly instructions for the display assembly. The display assembly must be disassembled to gain access to the backlight **(1)** and the liquid crystal display (LCD) panel **(2)**.




NOTE: The procedures provided in this chapter are general disassembly instructions. Specific details, such as screw sizes, quantities, and locations, and component shapes and sizes, can vary from one computer model to another.

Perform the following steps to disassemble the display assembly:


1. Remove all screw covers (1) and screws (2) that secure the display bezel to the display assembly.




2. Lift up and out on the left and right inside edges (1) and the top and bottom inside edges (2) of the display bezel until the bezel disengages from the display assembly.
3. Remove the display bezel (3).




4. Disconnect all display panel cables (1) from the display inverter and remove the inverter (2).



5. Remove all screws (1) that secure the display panel assembly to the display enclosure.
6. Remove the display panel assembly (2) from the display enclosure.




7. Position the display panel assembly upside-down.
8. Remove all screws that secure the display panel frame to the display panel.




9. Use a sharp-edged tool to cut the tape (1) that secures the sides of the display panel to the display panel frame.

10. Remove the display panel frame (2) from the display panel.



11. Remove the screws (1) that secure the backlight cover to the display panel.


12. Lift the top edge of the backlight cover (2) and swing it outward.



13. Remove the backlight cover.

14. Position the display panel right-side up.


15. Remove the backlight cables (1) from the clip (2) in the display panel.




16. Position the display panel upside-down.

⚠ WARNING! The backlight contains mercury. Exercise caution when removing and handling the backlight to avoid damaging this component and causing exposure to the mercury.

17. Remove the backlight frame from the display panel.



18. Remove the backlight from the backlight frame.




19. Disconnect the display panel cable (1) from the LCD panel.


20. Remove the screws (2) that secure the LCD panel to the display rear panel.

21. Release the LCD panel (3) from the display rear panel.

22. Release the tape (4) that secures the LCD panel to the display rear panel.



23. Remove the LCD panel.



24. Recycle the LCD panel and backlight.

Index

- A**
 - AC adapter, spare part numbers 28
 - AC adapter/battery light 15
 - advanced system diagnostics 88, 93, 97
 - antennas
 - disconnecting 47
 - audio board
 - removal 59
 - spare part number 23, 59
 - audio cable
 - illustrated 27
 - audio, product description 2
 - audio-in (microphone) jack 13
 - audio-out (headphone) jack 13
- B**
 - Backup and recovery
 - SUSE Linux 112
 - Windows 7 103
 - Windows 8 108
 - Backup and Restore 108
 - base enclosure, spare part number 23
 - battery
 - removal 38
 - spare part number 23, 38
 - battery bay 17
 - battery cable
 - removal 68
 - spare part number 68
 - battery connector cable,
 - illustrated 27
 - battery release latches 17
 - BIOS
 - SUSE Linux determining version 95
 - SUSE Linux downloading an update 96
 - SUSE Linux updating 95
 - Windows 7 determining version 86
 - Windows 7 downloading an update 87
 - Windows 7 updating 85
 - Windows 8 determining version 91
 - Windows 8 downloading an update 92
 - Windows 8 updating 91
 - Blu-ray BD-R/RE DVD±RW SuperMulti DL Drive 100
 - spare part number 28
 - Blu-ray Disc ROM with SuperMulti DVD±R/RW DL Drive
 - spare part number 40
 - Blu-ray ROM DVD±RW SuperMulti DL Drive
 - spare part number 24
 - Bluetooth card, spare part number 47
 - bottom door
 - removal 39
 - spare part number 24, 39
 - buttons
 - left TouchPad 7
 - optical drive eject 14
 - power 10
 - right TouchPad 7
 - Web browser button 10
 - wireless 10
- C**
 - Cable Kit
 - contents 27
 - spare part number 27
 - cables, service considerations 33
 - caps lock light, identifying 8
 - card reader board
 - removal 61
 - spare part number 61
 - chipset, product description 1
 - components
 - bottom 17
 - bottom parts 18
 - display 15
 - front 13
 - left side 14
 - right side 14
 - top 7
 - computer reset 111, 114
 - Computer Setup
 - SUSE Linux 94
 - SUSE Linux navigating and selecting 94
 - SUSE Linux restoring factory settings 95
 - Windows 7 84
 - Windows 7 navigating and selecting 84
 - Windows 7 restoring factory settings 85
 - Windows 8 90
 - Windows 8 navigating and selecting 90
 - Windows 8 restoring factory settings 91
 - computer specifications 98
 - connectors, service considerations 33
- D**
 - Device Manager
 - Windows 7 102
 - Windows 8 101
 - diskette drive, precautions 33
 - display assembly
 - removal 77
 - spare part numbers 77
 - display bezel
 - removal 80
 - spare part number 25
 - display component recycling 118
 - display components, spare part numbers 25
 - display hinge
 - removal 83
 - display hinge cover
 - spare part numbers 25
 - Display Hinge Kit
 - spare part number 25

- display panel
 - product description 1
 - removal 81
- display specifications 99
- drives
 - optical 14
 - preventing damage 33
- DVD-ROM Drive
 - precautions 33
 - spare part number 24, 28
 - specifications 101
- DVD±RW and CD-RW SuperMulti DL Combo Drive
 - precautions 33
 - removal 40
 - spare part number 40
- E**
- electrostatic discharge 34
- embedded numeric keypad, identifying 11, 12
- esc key, identifying 11
- Ethernet, product description 2
- external media cards, product description 3
- external monitor port 15
- F**
- f11 recovery
 - Windows 7 106
 - Windows 8 109
- fan
 - removal 52
 - spare part number 24, 52
- fingerprint reader
 - identifying 10
 - spare part number 23
- fn key, identifying 11, 12
- Function button/power button
 - removal 62
- function keys
 - identifying 11, 12
- G**
- graphics, product description 1
- grounding equipment and methods 36
- H**
- hard drive
 - precautions 33
- product description 2
- removal 43
- spare part numbers 24, 28, 29, 43
- specifications 99
- hard drive bracket, removal 45
- Hard Drive Hardware Kit, spare part number 28, 43
- hard drive light 13
- hard drive recovery 109
- HDMI port, identifying 15
- heat sink
 - removal 69
 - spare part number 24, 69
- hinge
 - removal 83
- hinge cover
 - spare part number 25
- I**
- integrated webcam light, identifying 16
- internal display switch 16
- internal microphones, identifying 16
- J**
- jacks
 - audio-in (microphone) 13
 - audio-out (headphone) 13
 - network 15
 - RJ-45 (network) 15
- K**
- keyboard
 - product description 3
 - removal 49
 - spare part numbers 23, 49
- keypad, embedded numeric 11, 12
- keys
 - esc 11, 12
 - fn 11, 12
 - function 11, 12
 - num lk 12
 - Operating system logo 12
 - Windows applications 11, 12
 - Windows logo 11
- L**
- legacy support, USB 84, 90, 94
- lights
 - AC adapter/battery light 15
 - caps lock 8
 - hard drive 13
 - optical drive 14
 - power 8
 - TouchPad 8
 - webcam 16
 - wireless 8
- M**
- mass storage devices, spare part numbers 28
- Media Card Reader 13
- memory module
 - product description 1
 - removal 45
 - spare part numbers 24, 45
- metal heat shield
 - removal 51
 - spare part number 23
- microphone (audio-in) jack
 - product description 2
- model name 1
- N**
- network jack, identifying 15
- num lk key, identifying 12
- O**
- Operating system logo key, identifying 12
- Operating system, product description 4
- optical drive 14
 - eject button 14
 - light 14
 - precautions 33
 - product description 2
 - protective insert illustrated 26
 - removal 40
 - spare part numbers 24, 28, 40
 - specifications 100, 101
- P**
- packing guidelines 35
- plastic parts 32
- Plastics Kit, spare part number 26
- pointing device, product description 3

- ports
 - external monitor 15
 - HDMI 15
 - product description 3
 - USB 14
- power button, identifying 10
- Power button/function button removal 62
- power cable
 - removal 76
 - spare part number 76
- power connector cable, illustrated 27
- power connector, identifying 14
- power cord
 - set requirements 116
 - spare part numbers 28
- power lights 8
- power requirements, product description 3
- power settings
 - SUSE Linux 10
 - Windows 7 10
 - Windows 8 10
- power/function board
 - spare part number 23
- processor
 - product description 1
 - removal 72
 - spare part numbers 24, 72
- product description
 - audio 2
 - chipset 1
 - display panel 1
 - Ethernet 2
 - external media cards 3
 - graphics 1
 - hard drives 2
 - keyboard 3
 - memory module 1
 - microphone 2
 - operating system 4
 - optical drives 2
 - pointing devices 3
 - ports 3
 - power requirements 3
 - processors 1
 - product name 1
 - security 3
 - serviceability 5
 - webcam 2
 - wireless 2
- product name 1
- R**
- recovery
 - Windows 8 110
- recovery partition
 - Windows 8 109
- recycle
 - computer 111, 114
- refresh
 - Windows 8 110
- release latches
 - battery 17
 - service door 17
- removal/replacement
 - preliminaries 32
 - procedures 37
- remove everything and reinstall
 - SUSE Linux 114
- remove everything and reinstall
 - Windows 8 111
- reset
 - computer 111
 - steps 111
 - SUSE Linux steps 114
- restoring the hard drive 109
- RJ-45 (network) jack, identifying 15
- RTC battery
 - removal 74
 - spare part number 23, 74
- S**
- Screw Kit, spare part number 28
- Secure Digital card insert, illustrated 26
- security cable slot, identifying 14
- security, product description 3
- service considerations 32
- service door release latches 17
- service door, identifying 18
- service tag 20, 37
- serviceability, product description 5
- setup utility
 - SUSE Linux navigating and selecting 94
 - SUSE Linux restoring factory settings 95
 - Windows 7 navigating and selecting 84
 - Windows 7 restoring factory settings 85
 - Windows 8 navigating and selecting 90
 - Windows 8 restoring factory settings 91
- slots
 - security cable 14
- speaker
 - removal 65
- speaker assembly
 - spare part number 23
- specifications
 - Blu-ray BD-R/RE DVD±RW SuperMulti DL Drive 100
 - computer 98
 - display 99
 - DVD-ROM Drive 101
 - hard drive 99
 - optical drive 100, 101
- static-shielding materials 36
- SUSE Linux
 - Backup and recovery 112
 - Computer Setup 94
 - keys 12
 - PCID label 21
 - power settings 10
 - reinstall 114
 - remove everything and reinstall option 114
 - reset 114
 - reset computer 114
- system board
 - removal 66
 - spare part numbers 23, 66
- T**
- thermal material, replacement 71
- tools required 32
- top cover
 - removal 53
 - spare part number 23, 53
- TouchPad
 - buttons 7
 - TouchPad light, identifying 8

- TouchPad zone
 - identifying 7
- transporting guidelines 35
- U**
- USB legacy support 84, 90, 94
- USB module
 - removal 63
 - spare part number 24
- USB module cable
 - illustrated 27
- USB ports, identifying 14, 15
- V**
- vents, identifying 15, 18
- W**
- Web browser button, identifying 10
- webcam 16
 - product description 2
 - spare part number 25
- webcam light, identifying 16
- webcam, identifying 16
- Windows 7
 - Backup and recovery 103
 - Computer Setup 84
 - Device Manager 102
 - f11 recovery 106
 - operating system DVD 107
 - PCID label 21
 - power settings 10
- Windows 8
 - Backup and recovery 108
 - Computer Setup 90
 - Device Manager 101
 - f11recovery 109
 - operating system DVD 110
 - PCID label 21
 - power settings 10
 - refresh 110
 - reinstall 111
 - remove everything and reinstall
 - option 111
 - reset 111
- Windows applications key,
 - identifying 11, 12
- Windows logo key, identifying 11
- wireless antennas
 - disconnecting 47
- wireless button, identifying 10
- wireless light 8
- wireless, product description 2
- WLAN antennas, identifying 16
- WLAN/Bluetooth combo card
 - removal 47
 - spare part numbers 24, 47
- workstation guidelines 35

