

Yield Reporting Form: HP LaserJet P1606 cartridge model CE278 Intro

Declaration of Yield

Toner cartridge yield:

Average cartridge yield 1000 standard pages¹

Declared yield value in accordance with ISO/IEC 19752

Toner lab data and results

Average ¹	1059
Standard Dev.	24
90% lower confidence limit ¹	1049

Test date: beginning	2009-3-19
Test dates: ending	2009-3-20
Number of cartridges used in testing	16
Number of cartridges used in calculations	16
Type of cartridge	Hewlett Packard Intro-CE278A all in one
Shake procedure used?	Yes, at first and second fade
Print mode	continuous
Job size	100 pages per job to 1900 pages, 25 thereafter
Number of engines used in testing	4
Media	HP Everyday 80g
Paper size	A4
Paper feed orientation	short edge
Computer model	HP Compaq dc7700
Operating system	Win XP
Application software	Adobe Reader 9.0
Print driver version	20091104
Connection type	USB
Test page version*	2004(E)

Power on/off every day	No
------------------------	----

Engine serial numbers:	Engine Firmware Version:
VNC3L00010	20091029
VNC3L00019	20091029
VNC3L00009	20091029
VNC3L00025	20091029

*filename: c034911_ISO_IEC_19752_2004(E)_Test_Page.pdf from ISO SC28 website

Cartridge testing data:

Intro-CE278A		LJ P1606dn	Humidity, %RH			Temperature, C			
Cartridge	Lot Code	Engine SerNo	Max	Min	Average	Max	Min	Average	Cartridge Yield
Intro-CE278A-001	9J08M1Dk	VNC3L00010	49.0	44.8	47.7	25.0	23.2	23.9	1095
Intro-CE278A-002	9J08M1Dk	VNC3L00019	49.0	44.8	47.7	25.0	23.2	23.9	1091
Intro-CE278A-003	9J08M1Dk	VNC3L00009	49.0	44.8	47.7	25.0	23.2	23.9	1070
Intro-CE278A-004	9J08M1Dk	VNC3L00025	49.0	44.8	47.7	25.0	23.2	23.9	1047
Intro-CE278A-005	9K10M1Dk	VNC3L00010	49.0	44.8	47.7	25.0	23.2	23.9	1058
Intro-CE278A-006	9K10M1Dk	VNC3L00019	49.0	44.8	47.7	25.0	23.2	23.9	1071
Intro-CE278A-007	9K10M1Dk	VNC3L00009	49.0	44.8	47.7	25.0	23.2	23.9	1077
Intro-CE278A-008	9K10M1Dk	VNC3L00025	49.0	44.8	47.7	25.0	23.2	23.9	1077
Intro-CE278A-009	9K10M1Dk	VNC3L00010	49.0	44.8	47.7	25.0	23.2	23.9	1079
Intro-CE278A-010	9K10M1Dk	VNC3L00019	49.0	44.8	47.7	25.0	23.2	23.9	1053
Intro-CE278A-011	9K12M1Dk	VNC3L00009	49.0	44.8	47.7	25.0	23.2	23.9	1037
Intro-CE278A-012	9K12M1Dk	VNC3L00025	49.0	44.8	47.7	25.0	23.2	23.9	1042
Intro-CE278A-013	9K12M1Dk	VNC3L00010	49.0	44.8	47.7	25.0	23.2	23.9	1060
Intro-CE278A-014	9K10M1Dk	VNC3L00019	49.0	44.8	47.7	25.0	23.2	23.9	1031
Intro-CE278A-015	9K10M1Dk	VNC3L00009	49.0	44.8	47.7	25.0	23.2	23.9	1055
Intro-CE278A-016	9K10M1Dk	VNC3L00025	49.0	44.8	47.7	25.0	23.2	23.9	1002

¹ In an ISO report commonly two values are listed: declared ISO yield and calculated test values. Generally, the calculated test values are higher than the declared ISO yield. Actual cartridge yields vary considerably based on content of images printed and other factors. For more information, visit www.hp.com/go/learnaboutsupplies.